

# CHEROKEE ARROW III

## INFORMATION MANUAL

Jump to Table of Contents



Cherokee Arrow III

PA-28R-201

HANDBOOK PART NO. 761 635

POH AND  
FAA APPROVED FLT MANUAL  
SECTION 2 - LIMITATIONS  
SECTION 9 - SUPP

Published by  
PUBLICATIONS DEPARTMENT  
Piper Aircraft Corporation  
Issued: December 21, 1976

REPORT: VB-870

## APPLICABILITY

The aircraft serial number eligibility bracket for application of this handbook is 28R-7737001 through 28R-7837317. The specific application of this handbook is limited to the Piper PA-28R-201 model airplane, designated by serial number and registration number on the face of the title page of this handbook.

This handbook cannot be used for operational purposes unless kept in a current status.

## REVISIONS

The information compiled in the Pilot's Operating Handbook will be kept current by revisions distributed to the airplane owners.

Revision material will consist of information necessary to update the text of the present handbook and/or to add information to cover added airplane equipment.

### I. Revisions

Revisions will be distributed whenever necessary as complete page replacements or additions and shall be inserted into the handbook in accordance with the instructions given below:

1. Revision pages will replace only pages with the same page number.
2. Insert all additional pages in proper numerical order within each section.
3. Page numbers followed by a small letter shall be inserted in direct sequence with the same common numbered page.

### II. Identification of Revised Material

Revised text and illustrations shall be indicated by a black vertical line along the outside margin of the page, opposite revised, added or deleted material. A line along the outside margin of the page opposite the page number will indicate that an entire page was added.

Black lines will indicate only current revisions with changes and additions to or deletions of existing text and illustrations. Changes in capitalization, spelling, punctuation or the physical location of material on a page will not be identified by symbols.

## ORIGINAL PAGES ISSUED

The original pages issued for this handbook prior to revision are given below:

Title, ii through v, 1-1 through 1-14, 2-1 through 2-8, 3-1 through 3-14, 4-1 through 4-18, 5-1 through 5-32, 6-1 through 6-56, 7-1 through 7-28, 8-1 through 8-16, 9-1 through 9-14, 10-1 through 10-2.

## PILOT'S OPERATING HANDBOOK LOG OF REVISIONS

Current Revisions to the PA-28R-201 Cherokee Arrow III Pilot's Operating Handbook, REPORT: VB-870 issued December 21, 1976.

Revision Number and Code	Revised Pages	Description of Revision	FAA Approval Signature and Date
Rev. 1 - 761 635 (PR770314)	1-3	Added Hartzell prop to item 1.5, Propellers.	<i>Ward Evans</i> Ward Evans March 14, 1977
	1-6	Corrected item 1.19 (b).	
	2-2	Added Hartzell prop. and (m) to item 2.7, Power Plant Limitations.	
	2-8	Added McCauley restriction to RPM limitation placard.	
	3-12	Revised item 3.27, Emergency Landing Gear Extension.	
	6-4	Revised Figure 6-3, Leveling Diagram.	
	6-17	Added items 1.a., 2.a. and 2.b.	
	6-19	Revised item 5 Cert. Basis.	
	6-53	Added 79591-2 Seat to item 287; added 79591-3 Seat to item 289.	
	7-3	Revised item 7.5, Engine and Propeller.	
7-28	Revised Note.		
Rev. 2 - 761 635 (PR770714)	1-11, 1-12, 1-13, 1-14	Revised para. 1.21, Conversion Factors.	
	3-3	Revised airspeeds under Engine Power Loss In Flight and Power Off Landing.	
	3-8	Revised airspeed under para. 3.11, Engine Power Loss In Flight.	
	3-9	Revised airspeeds under para. 3.13, Power Off Landing.	
	4-4	Revised RPM under Warm-Up.	
	4-5	Revised airspeed under Short Field, Obstacle Clearance and Soft Field Takeoff procedures.	
	4-13	Revised para. 4.23, Takeoff.	
	6-45	Added new item 213; revised item nos.; relocated item to pg. 6-46.	
	6-46	Added item from pg. 6-45; revised item nos.; added new items; relocated items to pg. 6-47.	
	6-47	Added items from pg. 6-46; added new items; relocated items to pg. 6-48.	
	6-48	Added items from pg. 6-47; added new items.	
	6-49	Revised item nos.; added new items; revised item 271.	
	6-53	Revised item nos.; revised items 327 and 331.	
	6-54	Revised item nos.; added new items; relocated item to pg. 6-55; revised item 353.	
	6-55	Added item 361 from pg. 6-54.	
7-18	Revised para. 7.21 Pitot-Static System.		
7-27	Revised para. 7.37, Piper External Power.		



**PILOT'S OPERATING HANDBOOK LOG OF REVISIONS (cont)**

Revision Number and Code	Revised Pages	Description of Revision	FAA Approval Signature and Date
Rev. 2 - 761 635 (PR770714) (cont)	9-7	Revised Section 1, second para.; revised Section 3; revised Section 4, Preflight item (c).	<i>Ward Evans</i> Ward Evans July 14, 1977
	9-8	Revised Section 4, Inflight items (a), (b) and (c).	
	9-9	Revised Section 1, second para.; revised Section 3 item (a) (1).	
	9-10	Revised Section 4, Inflight item (b).	
	9-11	Revised Section 4, Inflight items (d) (1), (2) and (3).	
Rev. 3 - 761 635 (PR781219)	1-4	Revised para. 1.13 and added footnote.	<i>Ward Evans</i> Ward Evans Dec. 19, 1978
	1-6	Revised spelling.	
	1-12	Revised ft.-lb. and kg conversions.	
	1-13	Revised spelling.	
	4-9	Revised items 4.13 (a), (b) and (c).	
	6-1	Revised para. 6.1 info.	
	6-37	Revised item 125.	
	6-44	Revised item 201.	
	6-53	Corrected revised date.	
	6-55	Revised item 361.	
	7-7	Revised para. 7.11 info.	
	7-17	Revised para. 7.17 info.	
	7-18	Revised para. 7.21 info.	
	7-25	Added caution to para. 7.29.	
Rev. 4 - 761 635 (PR790320)	7-27	Revised para. 7.39 info.	<i>Ward Evans</i> Ward Evans March 20, 1979
	8-i	Revised para. 8.27.	
	8-13	Revised para. 8.27.	
	2-3	Deleted item under 2.9 (c).	
	3-4	Revised item.	
	6-1	Revised para. 6.1 info.	
	7-4	Revised para. 7.9 info.	
Rev. 5 - 761 635 (PR810413)	7-6	Revised para. 7.11 info.	<i>Ward Evans</i> Ward Evans March 20, 1979
	7-15	Changed Note to Warning and revised.	
	8-9	Revised item No. 7 on Fig. 8-1.	
	8-13	Revised para. 8.27 info.	
	ii	Revised Warning.	
iii	Changed serial no. effectivities.	<i>Ward Evans</i> Ward Evans March 20, 1979	
2-1	Revised para. 2.1 info.		
3-1	Revised para. 3.1 info.		

**PILOT'S OPERATING HANDBOOK LOG OF REVISIONS (cont)**

Revision Number and Code	Revised Pages	Description of Revision	FAA Approval Signature and Date
Rev. 5 - 761 635 (PR810413) (cont)	3-13 3-14 4-1 6-3 6-55 7-15	Corrected heading. Corrected heading. Revised para. 4.1 info. Added Caution notice to para. 6.3 (a) (3). Corrected item 361. Revised Warning.	<i>Ward Evans</i> Ward Evans April 13, 1981
Rev. 6 - 761 635 (PR840313)	v 1-3 1-6 3-1 4-3, 4-4, 4-5 4-7 4-8 4-11 4-16 5-1 6-1 6-3 6-6 6-7 6-9, 6-10 7-3 7-14 7-25 8-3 8-4 8-6 8-11, 8-12 10-i 10-1, 10-2	Revised Table of Contents. Revised para. 1.7. Revised para. 1.19 (b). Revised para. 3.1. Revised para. 4.5.  Revised para. 4.9. Revised para. 4.11. Revised para. 4.17 and 4.19. Revised para. 4.33. Added Warning. Revised para. 6.1. Revised para. 6.3. Revised para. 6.5. Revised Fig. 6-5. Revised Fig. 6-7 and 6-7 (cont).  Revised para. 7.5. Revised para. 7.15. Revised para. 7.33. Revised para. 8.3. Revised para. 8.5. Revised para. 8.9 (b). Revised para. 8.21 (b) and (d).  Revised Table of Contents. Revised Titles, para. 10.1 and 10.3.	<i>Ward Evans</i> Ward Evans March 13, 1984
Rev. 7 - 761 635 (PR870131)	2-7 3-3, 3-4 3-7 3-9, 3-10 3-12	Revised para. 2.23. Revised para. 3.3.  Revised para. 3.9. Revised para. 3.13.  Revised para. 3.27.	

PILOT'S OPERATING HANDBOOK LOG OF REVISIONS (cont)

Revision Number and Code	Revised Pages	Description of Revision	FAA Approval Signature and Date
Rev. 7 - 761 635 (PR870131) (cont)	4-5 4-12 4-13 4-17 7-5 7-6 7-7 7-8 7-9 7-10	Revised para. 4.5. Revised para. 4.21. Revised para. 4.25. Revised para. 4.39. Revised fig. 7-1. Revised fig. 7-3. Revised para. 7.11. Revised para. 7.11. Revised fig. 7-5. Revised fig. 7-7. Revised fig. 7-9.	 D.H. Trompler <u>5/7/87</u> Date
Rev. 8 - 761 635 (PR890320)	1-i 1-3 1-4 3-i 3-1 4-i thru 4-ii 8-1 8-3 8-10 thru 8-11 9-9	Revised Table of Contents. Relocated para. 1.9 to pg. 1-4. Revised para. 1.9. Revised Table of Contents. Revised para. 3.1. Revised Table of Contents. Revised para. 8.1. Revised para. 8.3. Revised para. 8-19. Revised SECTION 3, (a).	 D.H. Trompler <u>May 1, 1989</u> Date

## TABLE OF CONTENTS

SECTION 1	GENERAL
SECTION 2	LIMITATIONS
SECTION 3	EMERGENCY PROCEDURES
SECTION 4	NORMAL PROCEDURES
SECTION 5	PERFORMANCE
SECTION 6	WEIGHT AND BALANCE
SECTION 7	DESCRIPTION AND OPERATION OF THE AIRPLANE AND ITS SYSTEMS
SECTION 8	AIRPLANE HANDLING, SERVICING AND MAINTENANCE
SECTION 9	SUPPLEMENTS
SECTION 10	OPERATING TIPS



TABLE OF CONTENTS

SECTION 1

GENERAL

Paragraph No.		Page No.
1.1	Introduction.....	1-1
1.3	Engines.....	1-3
1.5	Propellers .....	1-3
1.7	Fuel .....	1-3
1.9	Oil .....	1-4
1.11	Maximum Weights.....	1-4
1.13	Standard Airplane Weights .....	1-4
1.15	Baggage Space .....	1-4
1.17	Specific Loadings.....	1-4
1.19	Symbols, Abbreviations and Terminology.....	1-5
1.21	Conversion Factors .....	1-11

## SECTION 1

### GENERAL

#### 1.1 INTRODUCTION


This Pilot's Operating Handbook is designed for maximum utilization as an operating guide for the pilot. It includes the material required to be furnished to the pilot by C.A.R. 3 and FAR Part 21 Subpart J. It also contains supplemental data supplied by the airplane manufacturer.

This handbook is not designed as a substitute for adequate and competent flight instruction, knowledge of current airworthiness directives, applicable federal air regulations or advisory circulars. It is not intended to be a guide for basic flight instruction or a training manual and should not be used for operational purposes unless kept in a current status.

Assurance that the airplane is in an airworthy condition is the responsibility of the owner. The pilot in command is responsible for determining that the airplane is safe for flight. The pilot is also responsible for remaining within the operating limitations as outlined by instrument markings, placards, and this handbook.

Although the arrangement of this handbook is intended to increase its in-flight capabilities, it should not be used solely as an occasional operating reference. The pilot should study the entire handbook to familiarize himself with the limitations, performance, procedures and operational handling characteristics of the airplane before flight.

The handbook has been divided into numbered (arabic) sections each provided with a "finger-tip" tab divider for quick reference. The limitations and emergency procedures have been placed ahead of the normal procedures, performance and other sections to provide easier access to information that may be required in flight. The "Emergency Procedures" Section has been furnished with a red tab divider to present an instant reference to the section. Provisions for expansion of the handbook have been made by the deliberate omission of certain paragraph numbers, figure numbers, item numbers and pages noted as being intentionally left blank.



THREE VIEW

Figure 1-1

1.3 ENGINES

(a) Number of Engines		1
(b) Engine Manufacturer		Lycoming
(c) Engine Model Number		IO-360-C1C6
(d) Rated Horsepower		200
(e) Rated Speed (rpm)		2700
(f) Bore (inches)		5.125
(g) Stroke (inches)		4.375
(h) Displacement (cubic Inches)		361.0
(i) Compression Ratio		8.7:1
(j) Engine Type		Four Cylinder, Direct Drive, Horizontally Opposed, Air Cooled

1.5 PROPELLERS

(a) Number of Propellers		1
(b) Propeller Manufacturer	McCauley	or Hartzell
(c) Blade Model	90DHA-16	F7666A-2R
(d) Number of Blades	2	2
(e) Hub Model	B2D34C213	HC-C2YK-1( )/F
(f) Propeller Diameter (inches)		
(1) Maximum	74	74
(2) Minimum	73	72
(g) Propeller Type		Constant Speed, Hydraulically Actuated

1.7 FUEL

AVGAS ONLY

(a) Fuel Capacity (U.S. gal) (total)		77
(b) Usable Fuel (U.S. gal) (total)		72
(c) Fuel Grade, Aviation		
(1) Minimum Octane		Grade 100
(2) Specified Octane		100 Green or 100LL Blue
(3) Alternate Fuels		100/130 Green
		Refer to Fuel Requirements - Section 8.21 (b).

1.9 OIL

- (a) Oil Capacity (U.S. quarts) 8
- (b) Oil Specifications Refer to latest issue of  
Lycoming Service Instruction 1014.
- (c) Oil Viscosity per Average Ambient Temp. for Starting

Average Ambient Temperature	MIL-L-6082B SAE Grade	MIL-L-22851 Ashless Dispersant SAE Grades
All Temperatures	--	15W-50 or 20W-50
Above 80°F	60	60
Above 60°F	50	40 or 50
30°F to 90°F	40	40
0°F to 70°F	30	30, 40 or 20W-40
Below 10°F	20	30 or 20W-30

When operating temperatures overlap indicated ranges, use the lighter grade oil.

1.11 MAXIMUM WEIGHTS

- (a) Maximum Takeoff Weight (lbs) 2750
- (b) Maximum Landing Weight (lbs) 2750
- (c) Maximum Weight in Baggage Compartment 200

1.13 STANDARD AIRPLANE WEIGHTS\*

- (a) Standard Empty Weight (lbs): Weight of a standard airplane including unusable fuel, full operating fluids and full oil. 1622
- (b) Maximum Useful Load (lbs): The difference between the Maximum Takeoff Weight and the Standard Empty Weight. 1128

1.15 BAGGAGE SPACE

- (a) Compartment Volume (cubic feet) 24
- (b) Entry Width (inches) 22
- (c) Entry Height (inches) 20

1.17 SPECIFIC LOADINGS

- (a) Wing Loading (lbs per sq ft) 16.18
- (b) Power Loading (lbs per hp) 13.75

\*These values are approximate and vary from one aircraft to another. Refer to Figure 6-5 for the Standard Empty Weight value and the Useful Load value to be used for C.G. calculations for the aircraft specified.

### 1.19 SYMBOLS, ABBREVIATIONS AND TERMINOLOGY

The following definitions are of symbols, abbreviations and terminology used throughout the handbook and those which may be of added operational significance to the pilot.

(a) General Airspeed Terminology and Symbols

CAS	Calibrated Airspeed means the indicated speed of an aircraft, corrected for position and instrument error. Calibrated airspeed is equal to true airspeed in standard atmosphere at sea level.
KCAS	Calibrated Airspeed expressed in "Knots."
GS	Ground Speed is the speed of an airplane relative to the ground.
IAS	Indicated Airspeed is the speed of an aircraft as shown on the airspeed indicator when corrected for instrument error. IAS values published in this handbook assume zero instrument error.
KIAS	Indicated Airspeed expressed in "Knots."
M	Mach Number is the ratio of true airspeed to the speed of sound.
TAS	True Airspeed is the airspeed of an airplane relative to undisturbed air which is the CAS corrected for altitude, temperature and compressability.
$V_A$	Maneuvering Speed is the maximum speed at which application of full available aerodynamic control will not overstress the airplane.
$V_{FE}$	Maximum Flap Extended Speed is the highest speed permissible with wing flaps in a prescribed extended position.
$V_{LE}$	Maximum Landing Gear Extended Speed is the maximum speed at which an aircraft can be safely flown with the landing gear extended.
$V_{LO}$	Maximum Landing Gear Operating Speed is the maximum speed at which the landing gear can be safely extended or retracted.
$V_{NE}/M_{NE}$	Never Exceed Speed or Mach Number is the speed limit that may not be exceeded at any time.
$V_{NO}$	Maximum Structural Cruising Speed is the speed that should not be exceeded except in smooth air and then only with caution.

$V_S$	Stalling Speed or the minimum steady flight speed at which the airplane is controllable.
$V_{SO}$	Stalling Speed or the minimum steady flight speed at which the airplane is controllable in the landing configuration.
$V_X$	Best Angle-of-Climb Speed is the airspeed which delivers the greatest gain of altitude in the shortest possible horizontal distance.
$V_Y$	Best Rate-of-Climb Speed is the airspeed which delivers the greatest gain in altitude in the shortest possible time.

(b) Meteorological Terminology

ISA	International Standard Atmosphere in which: The air is a dry perfect gas; The temperature at sea level is 15° Celsius (59° Fahrenheit); The pressure at sea level is 29.92 inches hg. (1013.2 mb); The temperature gradient from sea level to the altitude at which the temperature is -56.5° C (-69.7° F) is -0.00198° C (-0.003566° F) per foot and zero above that altitude.
OAT	Outside Air Temperature is the free air static temperature, obtained either from inflight temperature indications or ground meteorological sources, adjusted for instrument error and compressibility effects.
Indicated Pressure Altitude	The number actually read from an altimeter when the barometric subscale has been set to 29.92 inches of mercury (1013 millibars).
Pressure Altitude	Altitude measured from standard sea-level pressure (29.92 in. Hg) by a pressure or barometric altimeter. It is the indicated pressure altitude corrected for position and instrument error. In this handbook, altimeter instrument errors are assumed to be zero.
Station Pressure	Actual atmospheric pressure at field elevation.
Wind	The wind velocities recorded as variables on the charts of this handbook are to be understood as the headwind or tailwind components of the reported winds.

(c) Power Terminology

Takeoff Power	Maximum power permissible for takeoff.
Maximum Continuous Power	Maximum power permissible continuously during flight.
Maximum Climb Power	Maximum power permissible during climb.
Maximum Cruise Power	Maximum power permissible during cruise.

(d) Engine Instruments

EGT Gauge	Exhaust Gas Temperature Gauge
-----------	-------------------------------

(e) Airplane Performance and Flight Planning Terminology

Climb Gradient	The demonstrated ratio of the change in height during a portion of a climb, to the horizontal distance traversed in the same time interval.
Demonstrated Crosswind Velocity	The demonstrated crosswind velocity is the velocity of the crosswind component for which adequate control of the airplane during takeoff and landing was actually demonstrated during certification tests.
Accelerate-Stop Distance	The distance required to accelerate an airplane to a specified speed and, assuming failure of an engine at the instant that speed is attained, to bring the airplane to a stop.
MEA	Minimum en route IFR altitude.
Route Segment	A part of a route. Each end of that part is identified by: (1) a geographical location; or (2) a point at which a definite radio fix can be established.



1.9 OIL

- (a) Oil Capacity (U.S. quarts) 8
- (b) Oil Specifications Refer to latest issue of  
Lycoming Service Instruction 1014.
- (c) Oil Viscosity per Average Ambient Temp. for Starting

Average Ambient Temperature	MIL-L-6082B SAE Grade	MIL-L-22851 Ashless Dispersant SAE Grades
All Temperatures	--	15W-50 or 20W-50
Above 80°F	60	60
Above 60°F	50	40 or 50
30°F to 90°F	40	40
0°F to 70°F	30	30, 40 or 20W-40
Below 10°F	20	30 or 20W-30

When operating temperatures overlap indicated ranges, use the lighter grade oil.

1.11 MAXIMUM WEIGHTS

- (a) Maximum Takeoff Weight (lbs) 2750
- (b) Maximum Landing Weight (lbs) 2750
- (c) Maximum Weight in Baggage Compartment 200

1.13 STANDARD AIRPLANE WEIGHTS\*

- (a) Standard Empty Weight (lbs): Weight of a standard airplane including unusable fuel, full operating fluids and full oil. 1622
- (b) Maximum Useful Load (lbs): The difference between the Maximum Takeoff Weight and the Standard Empty Weight. 1128

1.15 BAGGAGE SPACE

- (a) Compartment Volume (cubic feet) 24
- (b) Entry Width (inches) 22
- (c) Entry Height (inches) 20

1.17 SPECIFIC LOADINGS

- (a) Wing Loading (lbs per sq ft) 16.18
- (b) Power Loading (lbs per hp) 13.75

\*These values are approximate and vary from one aircraft to another. Refer to Figure 6-5 for the Standard Empty Weight value and the Useful Load value to be used for C.G. calculations for the aircraft specified.

### 1.19 SYMBOLS, ABBREVIATIONS AND TERMINOLOGY

The following definitions are of symbols, abbreviations and terminology used throughout the handbook and those which may be of added operational significance to the pilot.


(a) General Airspeed Terminology and Symbols


CAS	Calibrated Airspeed means the indicated speed of an aircraft, corrected for position and instrument error. Calibrated airspeed is equal to true airspeed in standard atmosphere at sea level.
KCAS	Calibrated Airspeed expressed in "Knots."
GS	Ground Speed is the speed of an airplane relative to the ground.
IAS	Indicated Airspeed is the speed of an aircraft as shown on the airspeed indicator when corrected for instrument error. IAS values published in this handbook assume zero instrument error.
KIAS	Indicated Airspeed expressed in "Knots."
M	Mach Number is the ratio of true airspeed to the speed of sound.
TAS	True Airspeed is the airspeed of an airplane relative to undisturbed air which is the CAS corrected for altitude, temperature and compressability.
$V_A$	Maneuvering Speed is the maximum speed at which application of full available aerodynamic control will not overstress the airplane.
$V_{FE}$	Maximum Flap Extended Speed is the highest speed permissible with wing flaps in a prescribed extended position.
$V_{LE}$	Maximum Landing Gear Extended Speed is the maximum speed at which an aircraft can be safely flown with the landing gear extended.
$V_{LO}$	Maximum Landing Gear Operating Speed is the maximum speed at which the landing gear can be safely extended or retracted.
$V_{NE}/M_{NE}$	Never Exceed Speed or Mach Number is the speed limit that may not be exceeded at any time.
$V_{NO}$	Maximum Structural Cruising Speed is the speed that should not be exceeded except in smooth air and then only with caution.

(f) Weight and Balance Terminology

Reference Datum	An imaginary vertical plane from which all horizontal distances are measured for balance purposes.
Station	A location along the airplane fuselage usually given in terms of distance from the reference datum.
Arm	The horizontal distance from the reference datum to the center of gravity (C.G.) of an item.
Moment	The product of the weight of an item multiplied by its arm. (Moment divided by a constant is used to simplify balance calculations by reducing the number of digits.)
Center of Gravity (C.G.)	The point at which an airplane would balance if suspended. Its distance from the reference datum is found by dividing the total moment by the total weight of the airplane.
C.G. Arm	The arm obtained by adding the airplane's individual moments and dividing the sum by the total weight.
C.G. Limits	The extreme center of gravity locations within which the airplane must be operated at a given weight.
Usable Fuel	Fuel available for flight planning.
Unusable Fuel	Fuel remaining after a runout test has been completed in accordance with governmental regulations.
Standard Empty Weight	Weight of a standard airplane including unusable fuel, full operating fluids and full oil.
Basic Empty Weight	Standard empty weight plus optional equipment.
Payload	Weight of occupants, cargo and baggage.
Useful Load	Difference between takeoff weight, or ramp weight if applicable, and basic empty weight.
Maximum Ramp Weight	Maximum weight approved for ground maneuver. (It includes weight of start, taxi and run up fuel.)
Maximum Takeoff Weight	Maximum weight approved for the start of the takeoff run.
Maximum Landing Weight	Maximum weight approved for the landing touchdown.
Maximum Zero Fuel Weight	Maximum weight exclusive of usable fuel.

THIS PAGE INTENTIONALLY LEFT BLANK





1.21' CONVERSION FACTORS

<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>	<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>
acres	0.4047	ha	cubic inches (cu. in.)	16.39	cm <sup>3</sup>
	43560	sq. ft.		$1.639 \times 10^{-5}$	m <sup>3</sup>
	0.0015625	sq. mi.		$5.787 \times 10^{-4}$	cu. ft.
atmospheres (atm)	76	cm Hg	0.5541	fl. oz.	
	29.92	in. Hg	0.01639	l	
	1.0133	bar	$4.329 \times 10^{-3}$	U.S. gal.	
	1.033	kg/cm <sup>2</sup>	0.01732	U.S. qt.	
	14.70	lb./sq. in.	cubic meters (m <sup>3</sup> )	61024	cu. in.
	2116	lb./sq. ft.		1.308	cu. yd.
bars (bar)	0.98692	atm.	35.3147	cu. ft.	
	14.503768	lb./sq. in.	264.2	U.S. gal.	
British Thermal Unit (BTU)	0.2519958	kg-cal	cubic meters per minute (m <sup>3</sup> /min.)	35.3147	cu. ft./min.
centimeters (cm)	0.3937	in.	cubic yards (cu. yd.)	27	cu. ft.
	0.032808	ft.		0.7646	m <sup>3</sup>
centimeters of mercury at 0°C (cm Hg)	0.01316	atm	202	U.S. gal.	
	0.3937	in. Hg	degrees (arc)	0.01745	radians
	0.1934	lb./sq. in.		degrees per second (deg./sec.)	0.01745
	27.85	lb./sq. ft.	drams, fluid (dr. fl.)		0.125
	135.95	kg/m <sup>2</sup>		drams, avdp. (dr. avdp.)	0.0625
centimeters per second (cm/sec.)	0.032808	ft./sec.	feet (ft.)		30.48
	1.9685	ft./min.		0.3048	m
	0.02237	mph		12	in.
cubic centimeters (cm <sup>3</sup> )	0.03381	fl. oz.		0.33333	yd.
	0.06102	cu. in.		0.0606061	rod
	$3.531 \times 10^{-5}$	cu. ft.	$1.894 \times 10^{-4}$	mi.	
	0.001	l	$1.645 \times 10^{-4}$	NM	
	$2.642 \times 10^{-4}$	U.S. gal.	feet per minute (ft./min.)	0.01136	mph
cubic feet (cu.ft.)	28317	cm <sup>3</sup>		0.01829	km/hr.
	0.028317	m <sup>3</sup>		0.508	cm/sec.
	1728	cu. in.		0.00508	m/sec.
	0.037037	cu. yd.		cubic feet per minute (cu. ft./min.)	0.472
	7.481	U.S. gal.	0.028317		m <sup>3</sup> /min.
28.32	l				

**SECTION 1  
GENERAL**

**PIPER AIRCRAFT CORPORATION  
PA-28R-201, CHEROKEE ARROW III**

<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>	<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>
feet per second (ft./sec.)	0.6818 1.097 30.48 0.5921	mph km/hr. cm/sec. kts.	hectares (ha)	2.471 107639 10000	acres sq. ft. m <sup>2</sup>
foot-pounds (ft.-lb.)	0.138255 3.24 x 10 <sup>-4</sup>	m-kg kg-cal	horsepower (hp)	33000 550 76.04 1.014	ft.-lb./min. ft.-lb./sec. m-kg/sec. metric hp
foot-pounds per minute (ft.-lb./min.)	3.030 x 10 <sup>-5</sup>	hp	horsepower, metric	75 0.9863	m-kg/sec. hp
foot-pounds per second (ft.-lb./sec.)	1.818 x 10 <sup>-5</sup>	hp	inches (in.)	25.40 2.540 0.0254 0.08333 0.027777	mm cm m ft. yd.
gallons, Imperial (Imperial gal.)	277.4 1.201 4.546	cu. in. U.S. gal. l	inches of mercury at 0°C (in. Hg)	0.033421 0.4912 70.73 345.3 2.540 25.40	atm lb./sq. in. lb./sq. ft. kg/m <sup>2</sup> cm Hg mm Hg
gallons, U.S. dry (U.S. gal. dry)	268.8 1.556 x 10 <sup>-1</sup> 1.164 4.405	cu. in. cu. ft. U.S. gal. l	inch-pounds (in.-lb.)	0.011521	m-kg
gallons, U.S. liquid (U.S. gal.)	231 0.1337 4.951 x 10 <sup>-3</sup> 3785.4 3.785 x 10 <sup>-3</sup> 3.785 0.83268 128	cu. in. cu. ft. cu. yd. cm <sup>3</sup> m <sup>3</sup> l Imperial gal. fl. oz.	kilograms (kg)	2.204622 35.27 1000	lb. oz. avdp. g
gallons per acre (gal./acre)	9.353	l/ha	kilogram-calories (kg-cal)	3.9683 3087 426.9	BTU ft.-lb. m-kg
grams (g)	0.001 0.3527 2.205 x 10 <sup>-3</sup>	kg oz. avdp. lb.	kilograms per cubic meter (kg/m <sup>3</sup> )	0.06243 0.001	lb./cu. ft. g/cm <sup>3</sup>
grams per centimeter (g/cm)	0.1 6.721 x 10 <sup>-2</sup> 5.601 x 10 <sup>-3</sup>	kg/m lb./ft. lb./in.	kilograms per hectare (kg/ha)	0.892	lb./acre
grams per cubic centimeter (g/cm <sup>3</sup> )	1000 0.03613 62.43	kg/m <sup>3</sup> lb./cu. in. lb./cu. ft.	kilograms per square centimeter (kg/cm <sup>2</sup> )	0.9678 28.96 14.22 2048	atm in. Hg lb./sq. in. lb./sq. ft.



<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>	<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>
kilograms per square meter (kg/m <sup>2</sup> )	2.896 x 10 <sup>-3</sup> 1.422 x 10 <sup>-3</sup> 0.2048	in. Hg lb./sq. in. lb./sq. ft.	meters per minute (m/min.)	0.06	km/hr.
kilometers (km)	1 x 10 <sup>-5</sup> 3280.8 0.6214 0.53996	cm ft. mi. NM	meters per second (m/sec.)	3.280840 196.8504 2.237 3.6	ft./sec. ft./min. mph km/hr.
kilometers per hour (km/hr.)	0.9113 58.68 0.53996 0.6214 0.27778 16.67	ft./sec. ft./min. kt mph m/sec. m/min.	microns	3.937 x 10 <sup>-5</sup>	in.
knots (kt)	1 1.689 1.1516 1.852 51.48	nautical mph ft./sec. statute mph km/hr. m/sec.	miles, statute (mi.)	5280 1.6093 1609.3 0.8684	ft. km m NM
liters (l)	1000 61.02 0.03531 33.814 0.264172 0.2200 1.05669	cm <sup>3</sup> cu. in. cu. ft. fl. oz. U.S. gal. Imperial gal. qt.	miles per hour (mph)	44.7041 4.470 x 10 <sup>-1</sup> 1.467 88 1.6093 0.8684	cm/sec. m/sec. ft./sec. ft./min. km/hr. kt
liters per hectare (l/ha)	13.69 0.107	fl. oz./acre gal./acre	miles per hour square (m/hr. sq.)	2.151	ft./sec. sq.
liters per second (l/sec.)	2.12	cu. ft./min.	millibars	2.953 x 10 <sup>-2</sup>	in. Hg
meters (m)	39.37 3.280840 1.0936 0.198838 6.214 x 10 <sup>-4</sup> 5.3996 x 10 <sup>-4</sup>	in. ft. yd. rod mi. NM	millimeters (mm)	0.03937	in.
meter-kilogram (m-kg)	7.23301 86.798	ft.-lb. in.-lb.	millimeters of mercury at 0°C (mm Hg)	0.03937	in. Hg
			nautical miles (NM)	6080 1.1516 1852 1.852	ft. statute mi. m km
			ounces, avdp. (oz. avdp.)	28.35 16	g dr. avdp.
			ounces, fluid (fl. oz.)	8 29.57 1.805 0.0296 0.0078	dr. fl. cm <sup>3</sup> cu. in. l U.S. gal.

SECTION 1  
GENERAL

PIPER AIRCRAFT CORPORATION  
PA-28R-201, CHEROKEE ARROW III

<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>	<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>
ounces, fluid per acre (fl. oz./acre)	0.073	l/ha	rod	16.5 5.5 5.029	ft. yd. m
pounds (lb.)	0.453592 453.6 $3.108 \times 10^{-2}$	kg g slug	slug	32.174	lb.
pounds per acre (lb./acre)	1.121	kg/ha	square centimeters (cm <sup>2</sup> )	0.1550 0.001076	sq. in. sq. ft.
pounds per cubic foot (lb./cu. ft.)	16.02	kg/m <sup>3</sup>	square feet (sq. ft.)	929 0.092903 144	cm <sup>2</sup> m <sup>2</sup> sq. in.
pounds per cubic inch (lb./cu. in.)	1728 27.68	lb./cu. ft. g/cm <sup>3</sup>	square inches (sq. in.)	0.1111 $2.296 \times 10^{-5}$	sq. yd. acres
pounds per square foot (lb./sq. ft.)	0.1414 4.88243 $4.725 \times 10^{-4}$	in. Hg kg/m <sup>2</sup> atm	square kilometers (km <sup>2</sup> )	6.4516 $6.944 \times 10^{-3}$	cm <sup>2</sup> sq. ft.
pounds per square inch (psi or lb./sq. in.)	5.1715 2.036 0.06804 0.0689476 703.1	cm Hg in. Hg atm bar kg/m <sup>2</sup>	square meters (m <sup>2</sup> )	10.76391 1.196 0.0001	sq. ft. sq. yd. ha
quart, U.S. (qt.)	0.94635 57.749	l cu. in.	square miles (sq. mi.)	2.590 640	km <sup>2</sup> acres
radians	57.30 0.1592	deg. (arc) rev.	square rods (sq. rods)	30.25	sq. yd.
radians per second (radians/sec.)	57.30 0.1592 9.549	deg./sec. rev./sec. rpm	square yards (sq. yd.)	0.8361 9 0.0330579	m <sup>2</sup> sq. ft. sq. rods
revolutions (rev.)	6.283	radians	yards (yd.)	0.9144 3 36 0.181818	m ft. in. rod
revolutions per minute (rpm or rev./min.)	0.1047	radians/sec.			
revolutions per second (rev./sec.)	6.283	radians/sec.			

TABLE OF CONTENTS

SECTION 2

LIMITATIONS

Paragraph No.		Page No.
2.1	General . . . . .	2-1
2.3	Airspeed Limitations . . . . .	2-1
2.5	Airspeed Indicator Markings . . . . .	2-2
2.7	Power Plant Limitations . . . . .	2-2
2.9	Power Plant Instrument Markings . . . . .	2-3
2.11	Weight Limits . . . . .	2-3
2.13	Center of Gravity Limits . . . . .	2-4
2.15	Maneuver Limits . . . . .	2-4
2.17	Flight Load Factors . . . . .	2-4
2.19	Types of Operations . . . . .	2-4
2.21	Fuel Limitations . . . . .	2-5
2.23	Placards . . . . .	2-5

SECTION 2  
LIMITATIONS

2.1 GENERAL

This section provides the "FAA Approved" operating limitations, instrument markings, color coding and basic placards necessary for operation of the airplane and its systems.

Limitations associated with those optional systems and equipment which require handbook supplements can be found in Section 9 (Supplements).

2.3 AIRSPEED LIMITATIONS

SPEED	KIAS	KCAS
Never Exceed Speed ( $V_{NE}$ ) - Do not exceed this speed in any operation.	183	186
Maximum Structural Cruising Speed ( $V_{NO}$ ) - Do not exceed this speed except in smooth air and then only with caution.	146	148
Design Maneuvering Speed ( $V_A$ ) - Do not make full or abrupt control movements above this speed.		
At 2750 LBS. G.W.	118	120
At 1865 LBS. G.W.	96	96

CAUTION

Maneuvering speed decreases at lighter weight as the effects of aerodynamic forces become more pronounced. Linear interpolation may be used for intermediate gross weights. Maneuvering speed should not be exceeded while operating in rough air.

Maximum Flaps Extended Speed ( $V_{FE}$ ) - Do not exceed this speed with the flaps extended.	103	103
Maximum Landing Gear Extension Speed - Do not exceed this speed when extending the landing gear.	129	130
Maximum Landing Gear Retraction Speed - Do not exceed this speed when retracting the landing gear.	107	107
Maximum Landing Gear Extended Speed ( $V_{LE}$ ) - Do not exceed this speed with the landing gear extended.	129	130

SECTION 2  
LIMITATIONS

PIPER AIRCRAFT CORPORATION  
PA-28R-201, CHEROKEE ARROW III

2.5 AIRSPEED INDICATOR MARKINGS

MARKING	KIAS
Red Radial Line (Never Exceed)	183
Yellow Arc (Caution Range - Smooth Air Only)	146 to 183
Green Arc (Normal Operating Range)	60 to 146
White Arc (Flap Down)	55 to 103

2.7 POWER PLANT LIMITATIONS

(a) Number of Engines		1
(b) Engine Manufacturer		Lycoming
(c) Engine Model No.		IO-360-C1C6
(d) Engine Operating Limits		200
(1) Maximum Horsepower		2700
(2) Maximum Rotation Speed (RPM)		245° F
(3) Maximum Oil Temperature		
(e) Oil Pressure		25 PSI
Minimum (red line)		90 PSI
Maximum (red line)		
(f) Fuel Pressure		14 PSI
Minimum (red line)		45 PSI
Maximum (red line)		Aviation Grade 100
(g) Fuel Grade (minimum octane)		1
(h) Number of Propellers		1
(i) Propeller Manufacturer	McCauley or	Hartzell
(j) Propeller Hub and Blade Model	B2D34C213/90DHA-16	HC-C2YK-1( ) F/F7666A-2R
(k) Propeller Diameter		72 IN.
Minimum	73 IN.	74 IN.
Maximum	74 IN.	
(l) Blade Angle Limits		14.0° ± 0.2°
Low Pitch Stop	12.5° ± 0.2°	29.0° ± 2.0°
High Pitch Stop	29.8° ± 0.5°	
(m) RPM Restriction (McCauley Prop Only)		Avoid continuous operation between 1500 and 1950 RPM below 15" manifold pressure

## 2.9 POWER PLANT INSTRUMENT MARKINGS

(a) Tachometer	
Green Arc (Normal Operating Range)	500 to 2700 RPM
Red Line (Maximum Continuous Power)	2700 RPM
(b) Oil Temperature	
Green Arc (Normal Operating Range)	75 to 245°F
Red Line (Maximum)	245°F
(c) Oil Pressure	
Green Arc (Normal Operating Range)	60 PSI to 90 PSI
Yellow Arc (Caution Range) (Idle)	25 PSI to 60 PSI
Red Line (Minimum)	25 PSI
Red Line (Maximum)	90 PSI
(d) Fuel Pressure	
Green Arc (Normal Operating Range)	14 PSI to 45 PSI
Red Line (Minimum)	14 PSI
Red Line (Maximum)	45 PSI

## 2.11 WEIGHT LIMITS

(a) Maximum Weight	2750 LBS
(b) Maximum Baggage	200 LBS

### NOTE

Refer to Section 5 (Performance) for maximum weight as limited by performance.

**SECTION 2  
LIMITATIONS**

**PIPER AIRCRAFT CORPORATION  
PA-28R-201, CHEROKEE ARROW III**

**2.13 CENTER OF GRAVITY LIMITS**

Weight Pounds	Forward Limit Inches Aft of Datum	Rearward Limit Inches Aft of Datum
2750	88.9	91.5
2375 & below	82	91.5

**NOTES**

Straight line variation between points given.

The datum used is 78.4 inches ahead of the wing leading edge at the inboard intersection of the straight and tapered section.

It is the responsibility of the airplane owner and the pilot to insure that the airplane is properly loaded. See Section 6 (Weight and Balance) for proper loading instructions.

**2.15 MANEUVER LIMITS**

No acrobatic maneuvers including spins approved.

**2.17 FLIGHT LOAD FACTORS**

- |                                    |                                |
|------------------------------------|--------------------------------|
| (a) Positive Load Factor (Maximum) | 3.8 G                          |
| (b) Negative Load Factor (Maximum) | No inverted maneuvers approved |

**2.19 TYPES OF OPERATIONS**

The airplane is approved for the following operations when equipped in accordance with FAR 91 or FAR 135.

- (a) Day V.F.R.
- (b) Night V.F.R.
- (c) Day I.F.R.
- (d) Night I.F.R.
- (e) Non Icing

2.21 FUEL LIMITATIONS

- (a) Total Capacity 77 U.S. GAL
- (b) Unusable Fuel 5 U.S. GAL  
The unusable fuel for this airplane has been determined as 2.5 gallons in each wing in critical flight attitudes.
- (c) Usable Fuel 72 U.S. GAL  
The usable fuel in this airplane has been determined as 36.0 gallons in each wing tank.
- (d) Fuel remaining when the quantity indicators read zero cannot be used safely in flight.

2.23 PLACARDS

In full view of the pilot:

“THIS AIRPLANE MUST BE OPERATED AS A NORMAL CATEGORY AIRPLANE IN COMPLIANCE WITH THE OPERATING LIMITATIONS STATED IN THE FORM OF PLACARDS, MARKINGS AND MANUALS.”

“THIS AIRCRAFT APPROVED FOR NIGHT I.F.R. NON-ICING FLIGHT WHEN EQUIPPED IN ACCORDANCE WITH FAR 91 OR FAR 135.”

In full view of the pilot, the following takeoff and landing check lists will be installed:

TAKEOFF CHECK LIST

Fuel on Proper Tank	Mixture - Set	Flaps - Set
Electric Fuel Pump - On	Propeller - Set	Trim Tab - Set
Engine Gauges - Checked	Fasten Belts/Harness	Controls - Free
Alternate Air - Closed		Doors - Latched
Seat Backs Erect		Air Conditioner - Off

LANDING CHECK LIST

Fuel on Proper Tank	Electric Fuel Pump - On	Gear Down (129 KIAS Max)
Seat Backs Erect	Mixture - Rich	Flaps - Set (103 KIAS Max)
Fasten Belts/Harness	Propeller - Set	Air Conditioner - Off

The “AIR CONDITIONER OFF” item in the above takeoff and landing check lists is mandatory for air conditioned aircraft only.

On the instrument panel in full view of the pilot:

“NO ACROBATIC MANEUVERS, INCLUDING SPINS APPROVED.”



On the instrument panel in full view of the pilot:

“MANEUVERING SPEED  
118 KIAS AT 2750  
LBS (SEE P.O.H.)”

On the instrument panel in full view of the pilot:

“DEMONSTRATED CROSSWIND COMPONENT 17 KTS”

On instrument panel in full view of the pilot:

“GEAR DOWN	129 KIAS (MAX)”
“GEAR UP	107 KIAS (MAX)”
“EXTENDED	129 KIAS (MAX)”

Near emergency gear lever:

“EMERGENCY DOWN”

Near emergency gear lever: (aircraft equipped with backup gear extender)

“OVERRIDE ENGAGED AUTO-EXT-OFF  
LOCK PIN ON SIDE  
TO ENGAGE OVERRIDE:  
PULL LEVER FULL UP, PUSH LOCK PIN  
TO RELEASE OVERRIDE:  
PULL LEVER FULL UP & RELEASE”

Near gear selector switch:

“GEAR UP	107 KIAS MAX”
“DOWN	129 KIAS MAX”

Adjacent to upper door latch (front and rear doors):

“ENGAGE LATCH BEFORE FLIGHT”

On the instrument panel in full view of the pilot:

“WARNING — TURN OFF STROBE LIGHTS WHEN IN  
CLOSE PROXIMITY TO GROUND, OR DURING FLIGHT  
THROUGH CLOUD, FOG, OR HAZE.”

In full view of pilot and over the fuel quantity gauges:

“FUEL REMAINING WHEN QUANTITY INDICATOR READS ZERO CANNOT BE USED SAFELY IN FLIGHT.”

In full view of the pilot, in the area of the air conditioner controls when the air conditioner is installed:

“WARNING – AIR CONDITIONER MUST BE OFF TO INSURE NORMAL TAKEOFF CLIMB PERFORMANCE.”

On inside of baggage compartment door:

“BAGGAGE MAXIMUM 200 LBS. SEE WEIGHT AND BALANCE DATA FOR BAGGAGE BETWEEN 150 LBS. AND 200 LBS.”

Adjacent to fuel tank filler caps:

“FUEL – 100/130 AVIATION GRADE MIN. – USABLE CAPACITY 36 GAL.”

“USABLE CAPACITY TO BOTTOM OF FILLER NECK INDICATOR 25 GAL.”

| On the instrument panel in full view of the pilot when McCauley propeller is installed:

“AVOID CONTINUOUS OPERATION BETWEEN 1500 AND 1950 RPM BELOW 15” MANIFOLD PRESSURE.”

**TABLE OF CONTENTS**  
**SECTION 3**  
**EMERGENCY PROCEDURES**

Paragraph No.		Page No.
3.1	General .....	3-1
3.3	Emergency Procedures Check List.....	3-3
	Engine Fire During Start .....	3-3
	Engine Power Loss During Takeoff .....	3-3
	Engine Power Loss On Flight .....	3-3
	Power Off Landing .....	3-3
	Fire In Flight.....	3-3
	Loss of Oil Pressure.....	3-4
	Loss of Fuel Pressure.....	3-4
	High Oil Temperature.....	3-4
	Alternator Failure .....	3-4
	Propeller Overspeed .....	3-4
	Emergency Landing Gear Extension.....	3-4
	Spin Recovery .....	3-4
	Open Door .....	3-5
3.5	Amplified Emergency Procedures (General) .....	3-7
3.7	Engine Fire During Start .....	3-7
3.9	Engine Power Loss During Takeoff .....	3-7
3.11	Engine Power Loss In Flight.....	3-8
3.13	Power Off Landing .....	3-9
3.15	Fire In Flight.....	3-10
3.17	Loss of Oil Pressure .....	3-11
3.19	Loss of Fuel Pressure .....	3-11
3.21	High Oil Temperature.....	3-11
3.23	Alternator Failure .....	3-12
3.25	Propeller Overspeed.....	3-12
3.27	Emergency Landing gear Extension.....	3-12
3.29	Spin Recovery .....	3-13
3.31	Open Door.....	3-13
3.33	Engine Roughness .....	3-13

## SECTION 3

### EMERGENCY PROCEDURES

#### 3.1 GENERAL

This section provides the recommended procedures for coping with various emergency or critical situations. All of the emergency procedures required by the FAA as well as those necessary for operation of the airplane, as determined by the operating and design features of the airplane, are presented.

Emergency procedures associated with optional systems and equipment which require handbook supplements are presented in Section 9, Supplements.

This section is divided into two basic parts. The first part contains the emergency procedures checklists. These checklists supply an immediate action sequence to be followed during critical situations with little emphasis on the operation of the systems.

The second part of the section provides amplified emergency procedures corresponding to the emergency procedures checklist items. These amplified emergency procedures contain additional information to provide the pilot with a more complete description of the procedures so they may be more easily understood.

Pilots must familiarize themselves with the procedures given in this section and must be prepared to take the appropriate action should an emergency situation arise. The procedures are offered as a course of action for coping with the particular situation or condition described. They are not a substitute for sound judgement and common sense.

Most basic emergency procedures are a normal part of pilot training. The information presented in this section is not intended to replace this training. This information is intended to provide a source of reference for the procedures which are applicable to this airplane. The pilot should review standard emergency procedures periodically to remain proficient in them.

**3.3 EMERGENCY PROCEDURES CHECK LIST**

**ENGINE FIRE DURING START**

Starter ..... crank engine  
Mixture ..... idle cut-off  
Throttle ..... open  
Electric fuel pump ..... OFF  
Fuel selector ..... OFF  
Abandon if fire continues

**ENGINE POWER LOSS DURING TAKEOFF**

If sufficient runway remains for a normal landing, leave gear down and land straight ahead.

If area ahead is rough, or if it is necessary to clear obstructions:

Gear selector switch ..... UP  
Emergency gear lever (on aircraft equipped with backup gear extender) .... locked in **OVERRIDE ENGAGED** position

If sufficient altitude has been gained to attempt a restart:

Maintain safe airspeed  
Fuel selector ..... switch to tank containing fuel  
Electric fuel pump ..... check ON  
Mixture ..... check RICH  
Alternate air ..... OPEN  
Emergency gear lever ..... as required  
If power is not regained, proceed with power off landing.

**ENGINE POWER LOSS IN FLIGHT**

Fuel selector ..... switch to tank containing fuel  
Electric fuel pump ..... ON  
Mixture ..... RICH  
Alternate air ..... OPEN  
Engine gauges ..... check for indication of cause of power loss  
If no fuel pressure is indicated, check tank selector position to be sure it is on a tank containing fuel.

When power is restored:

Alternate air ..... CLOSED  
Electric fuel pump ..... OFF

If power is not restored, prepare for power off landing.

Trim for 79 KIAS

**POWER OFF LANDING**

On aircraft equipped with the backup gear extender, lock the emergency gear lever in the "OVERRIDE ENGAGED" position before the airspeed drops below 105 KIAS to prevent the landing gear from free-falling.

Trim for 79 KIAS.

Locate suitable field.

Establish spiral pattern.

1000 ft above field at downwind position for normal landing approach.

When field can easily be reached, slow to 72 KIAS for shortest landing.

Touchdowns should normally be made at lowest possible airspeed with full flaps.

When committed to landing:

Ignition ..... OFF  
Master switch ..... OFF  
Fuel selector ..... OFF  
Mixture ..... idle cut-off  
Seat belt and harness ..... tight

**FIRE IN FLIGHT**

Source of fire ..... check

Electrical fire (smoke in cabin):

Master switch ..... OFF  
Vents ..... open  
Cabin heat ..... OFF  
Land as soon as practicable.

Engine fire:

Fuel selector ..... OFF  
Throttle ..... CLOSED  
Mixture ..... idle cut-off  
Electric fuel pump ..... check OFF  
Heater and defroster ..... OFF  
Proceed with power off landing procedure.

**LOSS OF OIL PRESSURE**

Land as soon as possible and investigate cause.  
Prepare for power off landing.

**LOSS OF FUEL PRESSURE**

Electric fuel pump ..... ON  
Fuel selector ..... check on full tank

**HIGH OIL TEMPERATURE**

Land at nearest airport and investigate the problem.  
Prepare for power off landing.

**ALTERNATOR FAILURE**

Verify failure.  
Reduce electrical load as much as possible.  
Alternator circuit breakers ..... check  
Alt switch ..... OFF (for 1 second),  
then on

If no output:  
Alt switch ..... OFF

Reduce electrical load and land as soon as practical.

If battery is fully discharged, the gear will have to be lowered using the emergency gear extension procedure. Position lights will not illuminate.

**PROPELLER OVERSPEED**

Throttle ..... retard  
Oil pressure ..... check  
Prop control ..... full DECREASE rpm,  
then set if any  
control available  
Airspeed ..... reduced  
Throttle ..... as required to remain  
below 2700 rpm

**EMERGENCY LANDING GEAR EXTENSION**

Prior to emergency extension procedure:  
Master switch ..... check ON  
Circuit breakers ..... check  
Panel lights ..... off (in daytime)

Gear indicator bulbs ..... check

If landing gear does not check down and locked:  
Airspeed ..... below 87 KIAS

Landing gear selector ..... DOWN  
Emergency gear lever (on aircraft equipped with  
backup gear extender) ..... OVERRIDE  
ENGAGED  
(while fishtailing airplane)

If landing gear does not check down and locked:  
Emergency gear lever .... EMERGENCY DOWN  
(while fishtailing airplane)

If all electrical power has been lost, the landing gear must be extended using the above procedures. The gear position indicator lights will not illuminate.

**SPIN RECOVERY**

Rudder ..... full opposite to  
direction of rotation  
Control wheel ..... full forward  
Ailerons ..... neutral  
Throttle ..... idle  
Rudder ..... neutral (when  
rotation stops)  
Wing flaps ..... up (if extended)  
Control wheel ..... as required to smoothly  
regain level flight altitude

**OPEN DOOR**

If both upper and side latches are open, the door will trail slightly open and airspeeds will be reduced slightly.

To close the door in flight:  
Slow airplane to 87 KIAS  
Cabin vents ..... close  
Storm window ..... open

If upper latch is open ..... latch  
If side latch is open ..... pull on armrest while  
moving latch handle to  
latched position

If both latches are open ..... latch side latch  
then top latch

### **3.5 AMPLIFIED EMERGENCY PROCEDURES (GENERAL)**

The following paragraphs are presented to supply additional information for the purpose of providing the pilot with a more complete understanding of the recommended course of action and probable cause of an emergency situation.

### **3.7 ENGINE FIRE DURING START**

Engine fires during start are usually the result of overpriming. The first attempt to extinguish the fire is to try to start the engine and draw the excess fuel back into the induction system.

If a fire is present before the engine has started, move the mixture control to idle cut-off, open the throttle and crank the engine. This is an attempt to draw the fire back into the engine.

If the engine has started, continue operating to try to pull the fire into the engine.

In either case (above), if fire continues more than a few seconds, the fire should be extinguished by the best available external means.

The fuel selector valves should be "OFF" and the mixture at idle cut-off if an external fire extinguishing method is to be used.

### **3.9 ENGINE POWER LOSS DURING TAKEOFF**

The proper action to be taken if loss of power occurs during takeoff will depend on the circumstances of the particular situation.

If sufficient runway remains to complete a normal landing, leave the landing gear down and land straight ahead.

If the area ahead is rough, or if it is necessary to clear obstructions, move the gear selector switch to the "UP" position. On aircraft equipped with the backup gear extender, lock the emergency gear lever in the "OVERRIDE ENGAGED" position.

If sufficient altitude has been gained to attempt a restart, maintain a safe airspeed and switch the fuel selector to another tank containing fuel. Check the electric fuel pump to ensure that it is "ON" and that the mixture is "RICH." The alternate air should be "OPEN."

On aircraft equipped with the backup gear extender, the landing gear will extend automatically when engine power fails at speeds below approximately 95 KIAS. The glide distance with the landing gear extended is roughly halved. If the situation dictates, the landing gear can be retained in the retracted position by locking the emergency gear lever in the "OVERRIDE ENGAGED" position.

If engine failure was caused by fuel exhaustion, power will not be regained after switching fuel tanks until the empty fuel lines are filled. This may require up to ten seconds.

If power is not regained, proceed with the Power Off Landing procedure (refer to the emergency check list and paragraph 3.13).

### 3.11 ENGINE POWER LOSS IN FLIGHT

Complete engine power loss is usually caused by fuel flow interruption and power will be restored shortly after fuel flow is restored. If power loss occurs at a low altitude, the first step is to prepare for an emergency landing (refer to paragraph 3.13). An airspeed of at least 79 KIAS should be maintained.

If altitude permits, switch the fuel selector to another tank containing fuel and turn the electric fuel pump "ON." Move the mixture control to "RICH" and the alternate air to "OPEN." Check the engine gauges for an indication of the cause of the power loss. If no fuel pressure is indicated, check the tank selector position to be sure it is on a tank containing fuel.

When power is restored move the alternate air to the "CLOSED" position and turn "OFF" the electric fuel pump.

If the preceding steps do not restore power, prepare for an emergency landing.

If time permits, turn the ignition switch to "L" then to "R" then back to "BOTH." Move the throttle and mixture control levers to different settings. This may restore power if the problem is too rich or too lean a mixture or if there is a partial fuel system restriction. Try other fuel tanks. Water in the fuel could take some time to be used up, and allowing the engine to windmill may restore power. If power is due to water, fuel pressure indications will be normal.

If engine failure was caused by fuel exhaustion power will not be restored after switching fuel tanks until the empty fuel lines are filled. This may require up to ten seconds.

If power is not regained, proceed with the Power Off Landing procedure (refer to the emergency check list and paragraph 3.13).



### 3.13 POWER OFF LANDING

If loss of power occurs at altitude, lock the emergency gear lever in the "OVERRIDE ENGAGED" position before airspeed drops to 105 KIAS to prevent the landing gear from inadvertently free-falling on aircraft equipped with the backup gear extender. Trim the aircraft for best gliding angle (79 KIAS, Air Cond. off) and look for a suitable field. If measures taken to restore power are not effective, and if time permits, check your charts for airports in the immediate vicinity; it may be possible to land at one if you have sufficient altitude. At best gliding angle, with the engine windmilling, and the propeller control in full "DECREASE rpm," the aircraft will travel approximately 1.6 miles for each thousand feet of altitude. If possible, notify the FAA by radio of your difficulty and intentions. If another pilot or passenger is aboard, let him help.

When you have located a suitable field, establish a spiral pattern around this field. Try to be at 1000 feet above the field at the downwind position, to make a normal landing approach. When the field can easily be reached, slow to 72 KIAS with flaps down for the shortest landing. Excess altitude may be lost by widening your pattern, using flaps or slipping, or a combination of these.

Whether to attempt a landing with gear up or down depends on many factors. If the field chosen is obviously smooth and firm, and long enough to bring the plane to a stop, the gear should be down. If there are stumps or rocks or other large obstacles in the field, the gear in the down position will better protect the occupants of the aircraft. If, however, the field is suspected to be excessively soft or short, or when landing in water of any depth, a wheels-up landing will normally be safer and do less damage to the airplane.

On aircraft equipped with the backup gear extender, the landing gear will free-fall at airspeeds below approximately 95 KIAS and will take six to eight seconds to be down and locked. If a gear up landing is desired, it will be necessary to lock the override lever in the "OVERRIDE ENGAGED" position before the airspeed drops to 105 KIAS to prevent the landing gear from inadvertently free falling.

Touchdown should normally be made at the lowest possible airspeed.

#### (a) Gear Down Landing

When committed to a gear down emergency landing, close the throttle control and shut "OFF" the master and ignition switches. Flaps may be used as desired. Turn the fuel selector valve to "OFF" and move the mixture to idle cut-off. The seat belts and shoulder harness (if installed) should be tightened. Touchdown should be normally made at the lowest possible airspeed.

Always remember that the automatic gear mechanism will extend the gear below approximately 95 KIAS with power off. Be prepared to lock the emergency gear lever in the "OVERRIDE ENGAGED" position before the airspeed drops to 105 KIAS to prevent the landing gear from inadvertently free falling, unless gear extension is desired.

#### NOTE

If the master switch is "OFF," the gear cannot be retracted.

(b) Gear Up Landing

On aircraft equipped with the backup gear extender, lock the emergency gear lever in the "OVERRIDE ENGAGED" position to prevent the gear from inadvertently extending at airspeeds below 105 KIAS.

Touchdowns should normally be made at the lowest possible airspeed with full flaps.

When committed to landing, turn "OFF" the ignition and master switch. The fuel selector should be "OFF" and the mixture at idle cut-off.

Tighten the seat belts and shoulder harness (if installed).

### 3.15 FIRE IN FLIGHT

The presence of fire is noted through smoke, smell and heat in the cabin. It is essential that the source of the fire be promptly identified through instrument readings, character of the smoke, or other indications since the action to be taken differs somewhat in each case.

Check for the source of the fire first.

If an electrical fire is indicated (smoke in the cabin), the master switch should be turned "OFF." The cabin vents should be opened and the cabin heat turned "OFF." A landing should be made as soon as possible.

If an engine fire is present, switch the fuel selector to "OFF" and close the throttle. The mixture should be at idle cut-off. Turn the electric fuel pump "OFF." In all cases, the heater and defroster should be "OFF." If radio communication is not required select master switch "OFF." If the terrain permits, a landing should be made immediately.

#### NOTE

The possibility of an engine fire in flight is extremely remote. The procedure given is general and pilot judgment should be the determining factor for action in such an emergency.

### 3.17 LOSS OF OIL PRESSURE

Loss of oil pressure may be either partial or complete. A partial loss of oil pressure usually indicates a malfunction in the oil pressure regulating system, and a landing should be made as soon as possible to investigate the cause and prevent engine damage.

A complete loss of oil pressure indication may signify oil exhaustion or may be the result of a faulty gauge. In either case, proceed toward the nearest airport, and be prepared for a forced landing. If the problem is not a pressure gauge malfunction, the engine may stop suddenly. Maintain altitude until such time as a dead stick landing can be accomplished. Don't change power settings unnecessarily, as this may hasten complete power loss.

Depending on the circumstances, it may be advisable to make an off airport landing while power is still available, particularly if other indications of actual oil pressure loss, such as sudden increases in temperatures, or oil smoke, are apparent, and an airport is not close.

If engine stoppage occurs, proceed with Power Off Landing.

### 3.19 LOSS OF FUEL PRESSURE

If loss of fuel pressure occurs, turn "ON" the electric fuel pump and check that the fuel selector is on a full tank.

If the problem is not an empty tank, land as soon as practical and have the engine-driven fuel pump and fuel system checked.

### 3.21 HIGH OIL TEMPERATURE

An abnormally high oil temperature indication may be caused by a low oil level, an obstruction in the oil cooler, damaged or improper baffle seals, a defective gauge, or other causes. Land as soon as practical at an appropriate airport and have the cause investigated.

A steady, rapid rise in oil temperature is a sign of trouble. Land at the nearest airport and let a mechanic investigate the problem. Watch the oil pressure gauge for an accompanying loss of pressure.

### **3.23 ALTERNATOR FAILURE**

Loss of alternator output is detected through zero reading on the ammeter. Before executing the following procedure, ensure that the reading is zero and not merely low by actuating an electrically powered device, such as the landing light. If no increase in the ammeter reading is noted, alternator failure can be assumed.

The electrical load should be reduced as much as possible. Check the alternator circuit breakers for a popped circuit.

The next step is to attempt to reset the overvoltage relay. This is accomplished by moving the "ALT" switch to "OFF" for one second and then to "ON." If the trouble was caused by a momentary overvoltage condition (16.5 volts and up) this procedure should return the ammeter to a normal reading.

If the ammeter continues to indicate "O" output, or if the alternator will not remain reset, turn off the "ALT" switch, maintain minimum electrical load and land as soon as practical. All electrical load is being supplied by the battery.

### **3.25 PROPELLER OVERSPEED**

Propeller overspeed is caused by a malfunction in the propeller governor or low oil pressure which allows the propeller blades to rotate to full low pitch.

If propeller overspeed should occur, retard the throttle and check the oil pressure. The propeller control should be moved to full "DECREASE rpm" and then set if any control is available. Airspeed should be reduced and throttle used to maintain 2700 RPM.

### **3.27 EMERGENCY LANDING GEAR EXTENSION**

Prior to proceeding with an emergency gear extension check to ensure that the master switch is "ON" and that the circuit breakers have not opened. If it is daytime, the panel lights should be turned off. Check the landing gear indicators for faulty bulbs.

#### **NOTE**

Refer to paragraph 4.39 for differences when emergency extension procedure is performed for training purposes.

If the landing gear does not check down and locked, reduce the airspeed to below 87 KIAS. Move the landing gear selector to the "DOWN" position. On aircraft equipped with the backup gear extender, place the emergency gear lever in the "OVERRIDE ENGAGED" position and fishtail the airplane.

If the landing gear still does not check down and locked, move the emergency gear lever to the "EMERGENCY DOWN" position while fishtailing the airplane.

If all electrical power has been lost, the landing gear must be extended using the above procedures. The gear position indicator lights will not illuminate.

### 3.29 SPIN RECOVERY

Intentional spins are prohibited in this airplane. If a spin is inadvertently entered, immediately apply opposite rudder, control wheel full forward while neutralizing ailerons then throttle to idle.

When the rotation stops, neutralize the rudder, retract the flaps if extended, and ease back on the control wheel as required to smoothly regain a level flight attitude.

### 3.31 OPEN DOOR

The cabin door on the Cherokee is double latched, so the chances of its springing open in flight at both the top and side are remote. However, should you forget the upper latch, or not fully engage the side latch, the door may spring partially open. This will usually happen at takeoff or soon afterward. A partially open door will not affect normal flight characteristics, and a normal landing can be made with the door open.

If both upper and side latches are open, the door will trail slightly open, and airspeed will be reduced slightly.

To close the door in flight, slow the airplane to 87 KIAS, close the cabin vents and open the storm window. If the top latch is open, latch it. If the side latch is open, pull on the armrest while moving the latch handle to the latched position. If both latches are open, close the side latch then the top latch.

### 3.33 ENGINE ROUGHNESS

Engine roughness may be caused by dirt in the injector nozzles, induction system icing, or ignition problems.

First adjust the mixture for maximum smoothness. The engine will run rough if the mixture is too rich or too lean.

Move the alternate air to "OPEN" and then turn "ON" the electric fuel pump.

Switch the fuel selector to another tank to see if fuel contamination is the problem.

Check the engine gauges for abnormal readings. If any gauge readings are abnormal proceed accordingly.

The magneto switch should then be moved to "L" then "R," then back to "BOTH." If operation is satisfactory on either magneto, proceed on that magneto at reduced power with full "RICH" mixture to a landing at the first available airport.

If roughness persists, prepare for a precautionary landing at pilot's discretion.

**TABLE OF CONTENTS**  
**SECTION 4**  
**NORMAL PROCEDURES**

Paragraph No.		Page No.
4.1	General .....	4-1
4.3	Airspeed for Safe Operation.....	4-1
4.5	Normal Procedures Check List .....	4.3
	Preflight Check.....	4-3
	Before Starting Engine .....	4-4
	Starting Engine When Cold.....	4-4
	Starting Engine When Hot.....	4-4
	Starting Engine When Flooded .....	4-4
	Starting With External Power Source.....	4-4
	Warm-Up .....	4-4
	Taxiing.....	4-4
	Ground Check.....	4-4
	Before Takeoff.....	4-5
	Takeoff.....	4-5
	Climb .....	4-5
	Cruising .....	4-5
	Approach and Landing .....	4-6
	Stopping Engine .....	4-6
	Parking.....	4-6
4.7	Amplified Normal Procedures (General) .....	4-7
4.9	Preflight Check.....	4-7
4.11	Before Starting Engine .....	4-8
4.13	Starting Engine.....	4-9
4.15	Warm-Up .....	4-11
4.17	Taxiing.....	4-11
4.19	Ground Check .....	4-11
4.21	Before Takeoff.....	4-12
4.23	Takeoff.....	4-13
4.25	Climb.....	4-13
4.27	Cruising .....	4-14
4.29	Approach and Landing .....	4-15
4.31	Stopping Engine .....	4-15
4.33	Parking .....	4-16

---

**TABLE OF CONTENTS**  
**SECTION 4**  
**NORMAL PROCEDURES**  
**(Continued)**

Paragraph No.	Page No.
4.35 Stalls .....	4-16
4.37 Turbulent Air Operation .....	4-16
4.39 Landing Gear .....	4-17
4.41 Weight and Balance .....	4-17

---

SECTION 4  
NORMAL PROCEDURES

4.1 GENERAL

This section clearly describes the recommended procedures for the conduct of normal operations for the Cherokee Arrow III. All of the required (FAA regulations) procedures and those necessary for operation of the airplane as determined by the operating and design features of the airplane are presented.

Normal procedures associated with those optional systems and equipment which require handbook supplements are provided by Section 9 (Supplements).

These procedures are provided to present a source of reference and review and to supply information on procedures which are not the same for all aircraft. Pilots should familiarize themselves with the procedures given in this section in order to become proficient in the normal operations of the airplane.

The first portion of this section consists of a short form check list which supplies an action sequence for normal operations with little emphasis on the operation of the systems.

The remainder of the section is devoted to amplified normal procedures which provide detailed information and explanations of the procedures and how to perform them. This portion of the section is not intended for use as an in-flight reference due to the lengthy explanations. The short form check list should be used for this purpose.


4.3 AIRSPEEDS FOR SAFE OPERATIONS

The following airspeeds are those which are significant to the safe operation of the airplane. These figures are for standard airplanes flown at gross weight under standard conditions at sea level.

Performance for a specific airplane may vary from published figures depending upon the equipment installed, the condition of the engine, airplane and equipment, atmospheric conditions and piloting technique.

(a) Best Rate of Climb Speed	
gear up, flaps up	90 KIAS
gear down, flaps up	78 KIAS
(b) Best Angle of Climb Speed	
gear up, flaps up	78 KIAS
gear down, flaps up	72 KIAS
(c) Turbulent Air Operating Speed (See Subsection 2.3)	118 KIAS
(d) Maximum Flap Speed	103 KIAS
(e) Landing Final Approach Speed (Flaps 40°)	75 KIAS
(f) Maximum Demonstrated Crosswind Velocity	17 KTS





WALK-AROUND

Figure 4-1

4.5 NORMAL PROCEDURES CHECKLIST

PREFLIGHT CHECK

- Control wheel ..... release belts
- Master switch ..... ON
- Fuel quantity gauges ..... check
- Master switch ..... OFF
- Ignition ..... OFF
- Exterior ..... check for damage
- Control surfaces ..... check for interference - free of ice, snow, frost
- Hinges ..... check for interference
- Wings ..... free of ice, snow, frost
- Stall warning ..... check
- Navigation lights ..... check
- Fuel tanks ..... check supply visually - secure caps
- Fuel tank sumps ..... drain, check for water, sediment and proper fuel
- Fuel vents ..... open
- Main gear struts ..... proper inflation (2.5 ± .25 in.)

- Tires ..... check
- Brake blocks ..... check
- Fuselage static vents ..... clear
- Pitot head ..... remove cover - holes clear
- Windshield ..... clean
- Propeller and spinner ..... check
- Engine baffle seals ..... check
- Fuel and oil ..... check for leaks
- Oil ..... check level
- Dipstick ..... properly seated
- Cowling ..... secure
- Inspection covers ..... secure
- Nose wheel tire ..... check
- Nose gear strut ..... proper inflation (2.75 ± .25 in.)
- Air inlets ..... clear
- Alternator belt ..... check tension
- Tow bar and control locks ..... stow
- Baggage ..... stowed properly - secure
- Baggage door ..... close and secure

**SECTION 4  
NORMAL PROCEDURES**

**PIPER AIRCRAFT CORPORATION  
PA-28R-201, CHEROKEE ARROW III**

Fuel strainer ..... drain  
Primary flight controls ..... proper operation  
Cabin doors ..... close and secure  
Required papers ..... on board  
Seat belts and harness ..... fastened - check  
inertial reel

**BEFORE STARTING ENGINE**

Parking brake ..... set  
Propeller ..... full INCREASE rpm  
Fuel selector ..... desired tank

**STARTING ENGINE WHEN COLD**

Throttle ..... 1/2" open  
Master switch ..... ON  
Electric fuel pump ..... ON  
Mixture ..... prime - then idle  
cut-off  
Starter ..... engage  
Mixture ..... full RICH  
Throttle ..... adjust  
Oil pressure ..... check

**STARTING ENGINE WHEN HOT**

Throttle ..... 1/2" open  
Master switch ..... ON  
Electric fuel pump ..... ON  
Mixture ..... idle cut-off  
Starter ..... engage  
Mixture ..... advance  
Throttle ..... adjust  
Oil pressure ..... check

**STARTING ENGINE WHEN FLOODED**

Throttle ..... open full  
Master switch ..... ON  
Electric fuel pump ..... OFF  
Mixture ..... idle cut-off  
Starter ..... engage  
Mixture ..... advance  
Throttle ..... retard  
Oil pressure ..... check

**STARTING WITH EXTERNAL POWER SOURCE**

Master switch ..... OFF  
All electrical equipment ..... OFF  
Terminals ..... connect  
External power plug ..... insert in  
fuselage

Proceed with normal start  
Throttle ..... lowest possible  
RPM

External power plug ..... disconnect from  
fuselage

Master switch ..... ON - check ammeter  
Oil pressure ..... check

**WARM-UP**

Throttle ..... 1400 to 1500 RPM

**TAXIING**

Parking brake ..... release  
Chocks ..... removed  
Taxi area ..... clear  
Throttle ..... apply slowly  
Prop ..... high RPM  
Brakes ..... check  
Steering ..... check

**GROUND CHECK**

Parking brake ..... set  
Propeller ..... full INCREASE  
Throttle ..... 2000 RPM  
Magnetos ..... max. drop 175 RPM  
- max. diff. 50 RPM

Vacuum ..... 4.8" Hg. to 5.1" Hg.  
Oil temp ..... check  
Oil pressure ..... check  
Air conditioner ..... check  
Annunciator panel ..... press-to-test  
Propeller ..... exercise - then  
full INCREASE

Alternate air ..... check  
Engine is warm for takeoff when throttle can be  
opened without engine faltering.

Electric fuel pump ..... OFF  
Fuel pressure ..... check  
Throttle ..... retard



### APPROACH AND LANDING

Fuel selector . . . . . proper tank  
Seat backs . . . . . erect  
Belts/harness . . . . . fasten  
Electric fuel pump . . . . . ON  
Mixture . . . . . set  
Propeller . . . . . set  
Gear . . . . . down - 129 KIAS max  
Flaps . . . . . set - 103 KIAS max  
Air conditioner . . . . . OFF  
Trim to 75 KIAS

### STOPPING ENGINE

Flaps . . . . . retract  
Electric fuel pump . . . . . OFF  
Air conditioner . . . . . OFF  
Radio's . . . . . OFF  
Propeller . . . . . full INCREASE  
Throttle . . . . . full aft  
Mixture . . . . . idle cut-off  
Magnetos . . . . . OFF  
Master switch . . . . . OFF

### PARKING

Parking brake . . . . . set  
Control wheel . . . . . secured with belts  
Flaps . . . . . full up  
Wheel chocks . . . . . in place  
Tie downs . . . . . secure

#### 4.7 AMPLIFIED NORMAL PROCEDURES (GENERAL)

The following paragraphs are provided to supply detailed information and explanations of the normal procedures necessary for the safe operation of the airplane.

#### 4.9 PREFLIGHT CHECK

The airplane should be given a thorough preflight and walk-around check. The preflight should include a check of the airplane's operational status, computation of weight and C.G. limits, takeoff distance and in-flight performance. A weather briefing should be obtained for the intended flight path, and any other factors relating to a safe flight should be checked before takeoff.

#### CAUTION

The flap position should be noted before boarding the airplane. The flaps must be placed in the "UP" position before they will lock and support weight on the step.

Upon entering the cockpit, release the seat belts securing the control wheel. Turn "ON" the master switch and check the fuel quantity gauges for sufficient fuel. After the fuel quantity check is made turn the master switch "OFF" and check that the ignition switch is "OFF."

To begin the exterior walk-around, check for external damage and operational interference of the control surfaces or hinges. Insure that the wings and control surfaces are free of snow, ice, frost or any other foreign materials.

An operational check of the stall warning system and exterior lights should now be made. Turn the master switch and appropriate light switches "ON." Lift the stall detector on the leading edge of the left wing while checking to determine that the warning horn is actuated, and check that navigation and anti-collision lights are illuminated. To check the optional heated pitot head, be sure to first remove any protective cover that might have been installed. With the heated pitot switch "ON" the pitot head should be found hot to touch. The master switch should be returned to the "OFF" position after these checks are complete.

A visual check of the fuel tank quantity should be performed. Remove the filler cap from each tank and visually check the supply and color. Be sure to secure the caps properly after the check is complete.

The fuel system tank sumps and strainer should be drained daily prior to the first flight and after refueling to avoid the accumulation of water or sediment. Each fuel tank is equipped with an individual quick drain located at the lower inboard rear corner of the tank. The fuel strainer is located on the left forward side of the fire wall.

Drain each tank through its individual quick drain located at the lower inboard rear corner of the tank, making sure that enough fuel has been drained to insure that all water and sediment is removed. Verify that proper fuel is in the tank.

CAUTION

When draining any amount of fuel, care should be taken to insure that no fire hazard exists before starting engine.

Check all of the fuel tank vents to make sure they are open.

Next, complete a check of the landing gear. Check the main gear shock struts for proper inflation. There should be  $2.5 \pm .25$  inches of strut exposure under a normal static load. The nose gear should be checked for  $2.75 \pm .25$  inches of strut exposure. Check all tires for cuts and wear and insure proper inflation. Make a visual check of the brake blocks for wear or damage.

Remove the cover from the pitot head on the underside of the left wing. Check the pitot head to make sure the holes are open and clear of obstructions. Check static vent holes on both sides of aft fuselage to make sure the holes are open and clear of obstructions.

Don't forget to clean and check the windshield.

The propeller and spinner should be checked for defects or nicks.

Lift the cowling and check for any obvious fuel or oil leaks. Check the oil level. Make sure that the dipstick has properly seated after checking. Secure the cowling and check the inspection covers.

Check the air inlets for foreign matter and the alternator belt for proper tension.

Stow the tow bar and check the baggage for proper storage and security. The baggage compartment doors should be closed and secure.

Upon entering the aircraft, ascertain that all primary flight controls operate properly. Close and secure the fore and aft cabin doors and check that all the required papers are in order and in the airplane.

Fasten the seat belts and shoulder harness and check the function of the inertia reel by pulling sharply on the strap. Fasten seat belts on empty seats.

**4.11 BEFORE STARTING ENGINE**

Before starting the engine the parking brake should be set "ON" and the propeller lever moved to the full "INCREASE" rpm position. The fuel selector should then be moved to the desired tank.

#### 4.13 STARTING ENGINE

(a) Starting Engine When Cold

Open the throttle lever approximately 1/2 inch. Turn "ON" the master switch and the electric fuel pump. Move the mixture control to full "RICH" until an indication is noted on the fuel flow meter. The engine is now primed.

Move the mixture control to idle cut-off and engage the starter by rotating the magneto switch clockwise. When the engine fires, release the magneto switch, advance the mixture control to full "RICH" and move the throttle to the desired setting.

If the engine does not fire within five to ten seconds, disengage the starter and reprime.

(b) Starting Engine When Hot

Open the throttle approximately 1/2 inch. Turn "ON" the master switch and the electric fuel pump. Move the mixture control lever to idle cut-off and engage the starter by rotating the magneto switch clockwise. When the engine fires, release the magneto switch, advance the mixture and move the throttle to the desired setting.

(c) Starting Engine When Flooded

The throttle lever should be full "OPEN." Turn "ON" the master switch and turn "OFF" the emergency fuel pump. Move the mixture control lever to idle cut-off and engage the starter by rotating the magneto switch clockwise. When the engine fires, release the magneto switch, advance the mixture and retard the throttle.

(d) Starting Engine With External Power Source

An optional feature called the Piper External Power (PEP) allows the operator to use an external battery to crank the engine without having to gain access to the airplane's battery.

Turn the master switch OFF and turn all electrical equipment OFF. Connect the RED lead of the PEP kit jumper cable to the POSITIVE (+) terminal of an external 12-volt battery and the BLACK lead to the NEGATIVE (-) terminal. Insert the plug of the jumper cable into the socket located on the fuselage. Note that when the plug is inserted, the electrical system is ON. Proceed with the normal starting technique.

After the engine has started, reduce power to the lowest possible RPM, to reduce sparking, and disconnect the jumper cable from the aircraft. Turn the master switch ON and check the alternator ammeter for an indication of output. DO NOT ATTEMPT FLIGHT IF THERE IS NO INDICATION OF ALTERNATOR OUTPUT.

NOTE

For all normal operations using the PEP jumper cables, the master switch should be OFF, but it is possible to use the ship's battery in parallel by turning the master switch ON. This will give longer cranking capabilities, but will not increase the amperage.

CAUTION

Care should be exercised because if the ship's battery has been depleted, the external power supply can be reduced to the level of the ship's battery. This can be tested by turning the master switch ON momentarily while the starter is engaged. If cranking speed increases, the ship's battery is at a higher level than the external power supply.

When the engine is firing evenly, advance the throttle to 800 RPM. If oil pressure is not indicated within thirty seconds, stop the engine and determine the trouble. In cold weather it will take a few seconds longer to get an oil pressure indication. If the engine has failed to start, refer to the Lycoming Operating Handbook, Engine Troubles and Their Remedies.

Starter manufacturers recommend that cranking periods be limited to thirty seconds with a two minute rest between cranking periods. Longer cranking periods will shorten the life of the starter.



#### 4.15 WARM-UP

Warm-up the engine at 1400 to 1500 RPM. Avoid prolonged idling at low RPM, as this practice may result in fouled spark plugs.

Takeoff may be made as soon as the ground check is completed, provided that the throttle may be opened fully without backfiring or skipping, and without a reduction in engine oil pressure.

Do not operate the engine at high RPM when running up or taxiing over ground containing loose stones, gravel or any loose material that may cause damage to the propeller blades.

#### 4.17 TAXIING

Before attempting to taxi the airplane, ground personnel should be instructed and approved by a qualified person authorized by the owner. Ascertain that the propeller back blast and taxi areas are clear.

After releasing the parking brake, power should be applied slowly to start the taxi roll. Taxi a few feet forward and apply the brakes to determine their effectiveness. Taxi with the propeller set in low pitch, high RPM setting. While taxiing, make slight turns to ascertain the effectiveness of the steering.

Observe wing clearances when taxiing near buildings or other stationary objects. If possible, station an observer outside the airplane.

Avoid holes and ruts when taxiing over uneven ground.

Do not operate the engine at high RPM when running up or taxiing over ground containing loose stones, gravel or any loose material that may cause damage to the propeller blades.

#### 4.19 GROUND CHECK

Set the parking brake.

The magnetos should be checked at 2000 RPM with the propeller set at high RPM. Drop off on either magneto should not exceed 175 RPM and the difference between the magnetos should not exceed 50 RPM. Operation on one magneto should not exceed 10 seconds.

Check the vacuum gauge; the indicator should read 4.8" Hg to 5.1" Hg at 2000 RPM.

Check the annunciator panel lights with the press-to-test button. Also check the air conditioner and the alternate air.

Release the parking brake.

The propeller control should be moved through its complete range to check for proper operation and then placed in full "INCREASE" rpm for takeoff. To obtain maximum rpm, push the pedestal mounted control fully forward on the instrument panel. Do not allow a drop of more than 500 RPM during this check. In cold weather the propeller control should be cycled from high to low RPM at least three times before takeoff to make sure that warm engine oil has circulated.

The electric fuel pump should be turned "OFF" after starting or during warm-up to make sure that the engine driven pump is operating. Prior to takeoff the electric pump should be turned ON again to prevent loss of power during takeoff should the engine driven pump fail. Check both oil temperature and oil pressure. The temperature may be low for some time if the engine is being run for the first time of the day. The engine is warm enough for takeoff when the throttle can be opened without the engine faltering.

#### **4.21 BEFORE TAKEOFF**

All aspects of each particular takeoff should be considered prior to executing the takeoff procedure.

After takeoff on aircraft equipped with the backup gear extender, if the gear selector switch is placed in the gear up position before reaching the airspeed at which the system no longer commands gear down\*, the gear will not retract. For obstacle clearance on takeoff and for takeoffs from high altitude airports, the landing gear can be retracted after lift-off at the pilot's discretion by placing the gear selector switch in the "UP" position and then locking the emergency gear lever in the "OVERRIDE ENGAGED" position. If desired, the "OVERRIDE ENGAGED" position can be selected and locked before takeoff, and the gear will then retract as soon as the gear selector switch is placed in the "UP" position. Care should always be taken not to retract the gear prematurely, or the aircraft could settle back onto the runway. If the override lock is used for takeoff, it should be disengaged as soon as sufficient airspeed and terrain clearance are obtained, to return the gear system to normal operation. For normal operation, the pilot should extend and retract the gear with the gear selector switch located on the instrument panel, just as he would if the backup gear extender system were not installed.

After all aspects of the takeoff are considered, a pretakeoff check procedure must be performed.

Turn "ON" the master switch and check and set all of the flight instruments as required. Check the fuel selector to make sure it is on the proper tank (fullest). Turn "ON" the electric fuel pump and check the engine gauges. The alternate air should be in the "CLOSED" position.

All seat backs should be erect.

The mixture and propeller control levers should be set and the seat belts and shoulder harness fastened. Fasten the seat belts snugly around the empty seats.

Exercise and set the flaps and trim tab. Ensure proper flight control movement and response.

All doors should be properly secured and latched.

On air conditioned models, the air conditioner must be "OFF" to ensure normal takeoff performance.

\*Approximately 75 KIAS at sea level to approximately 88 KIAS at 10,000 ft with a straight line variation between.

#### 4.23 TAKEOFF

The normal takeoff technique is conventional for the Cherokee Arrow III. The tab should be set slightly aft of neutral, with the exact setting determined by the loading of the airplane. Allow the airplane to accelerate to 65 to 75 KIAS depending on the weight of the aircraft and ease back on the control wheel to rotate to climb attitude.

The procedure used for a short field takeoff with an obstacle or a soft field takeoff differs slightly from the normal technique. The flaps should be lowered to 25° (second notch). Allow the aircraft to accelerate to 50 to 60 KIAS depending on the aircraft weight and rotate the aircraft to climb attitude. After breaking ground, accelerate to 55 to 65 KIAS, depending on aircraft weight and select gear up\*. Continue to climb while accelerating to the flaps up rate of climb speed, 90 KIAS if no obstacle is present or to the best flaps up angle of climb speed, 78 KIAS if obstacle clearance is a consideration. Retract the flaps slowly, one notch at a time, while climbing out.

#### 4.25 CLIMB

The best rate of climb at gross weight will be obtained at 90 KIAS. The best angle of climb may be obtained at 78 KIAS. At lighter than gross weight these speeds are reduced somewhat\*\*. For climbing en route, a speed of 104 KIAS is recommended. This will produce better forward speed and increased visibility over the nose during the climb.

When reaching the desired altitude, the electric fuel pump may be turned off.

#### NOTE

On aircraft equipped with the backup gear extender, during climbs at best angle of climb speed at any altitude and best rate of climb speed above approximately 15,000 feet density altitude it may be necessary to select "OVERRIDE ENGAGED" to prevent the landing gear from extending automatically during the climb. This altitude decreases with reduced climb power and increases with increased climb speed.

\*If desired, on aircraft equipped with the backup gear extender the "OVERRIDE ENGAGED" position can be selected and locked before takeoff, and the gear will then retract as soon as the gear selector switch is placed in the up position. In this case care should be taken not to retract the gear prematurely, or the aircraft could settle back onto the runway. If the override lock is used for takeoff, it should be disengaged as soon as sufficient terrain clearance is obtained, to return the gear system to normal operation.

\*\*To obtain the performance presented in the Performance Section of this handbook, full power (full throttle and 2700 RPM) must be used.

#### 4.27 CRUISING

The cruising speed of the Cherokee Arrow III is determined by many factors, including power setting, altitude, temperature, loading and equipment installed in the airplane.

The normal maximum cruising power is 75% of the rated horsepower of the engine. When selecting cruising RPM below 2400, limiting manifold pressure for continuous operation, as specified by the appropriate "Avco-Lycoming Operator's Manual," should be observed.

To obtain the desired power, set the manifold pressure and RPM according to the power setting table in this manual.

Use of the mixture control in cruising flight reduces fuel consumption significantly, especially at higher altitudes. The mixture should be leaned during cruising operation when 75% power or less is being used. If any doubt exists as to the amount of power being used, the mixture should be in the full "RICH" position for all operations.

To lean the mixture, disengage the lock and pull the mixture control until the engine becomes rough, indicating that the lean mixture limit has been reached in the leaner cylinders. Then enrich the mixture by pushing the control towards the instrument panel until engine operation becomes smooth. The fuel flow meter will give a close approximation of the fuel being consumed. The low side of the power setting, as shown on the fuel flow meter, indicates best economy for that percent of power while the high side indicates best power.

If the airplane is equipped with the optional exhaust gas temperature (EGT) gauge, a more accurate means of leaning is available to the pilot. For this procedure, refer to the "Avco-Lycoming Operator's Manual."

In order to keep the airplane in best lateral trim during cruise flight, the fuel should be used alternately from each tank at one hour intervals.

Always remember that the electric fuel pump should be turned "ON" before switching tanks, and should be left on for a short period thereafter. To preclude making a hasty selection, and to provide continuity of flow, the selector should be changed to another tank before fuel is exhausted from the tank in use. The electric fuel pump should be normally "OFF" so that any malfunction of the engine driven fuel pump is immediately apparent. If signs of fuel starvation should occur at any time during flight, fuel exhaustion should be suspected, at which time the fuel selector should be immediately positioned to a full tank and the electric fuel pump switched to the "ON" position.

#### 4.29 APPROACH AND LANDING

Check to insure the fuel selector is on the proper (fullest) tank and that the seat backs are erect. The seat belts and shoulder harness should be fastened and the inertia reel checked.

Turn "ON" the electric fuel pump and turn "OFF" the air conditioner. The mixture should be set in the full "RICH" position. Set the propeller at full "INCREASE" rpm to facilitate ample power for an emergency go-around.

The landing gear may be extended at speeds below 129 KIAS. The airplane should be trimmed to a final approach speed of about 75 KIAS with flaps extended. The flaps can be lowered at speeds up to 103 KIAS, if desired.

The mixture control should be kept in full "RICH" position to insure maximum acceleration if it should be necessary to open the throttle again.

The amount of flap used during landings and the speed of the aircraft at contact with the runway should be varied according to the landing surface and conditions of wind and airplane loading. It is generally good practice to contact the ground at the minimum possible safe speed consistent with existing conditions.

Normally, the best technique for short and slow landings is to use full flap and enough power to maintain the desired airspeed and approach flight path. Mixture should be full "RICH," fuel on the fullest tank, and electric fuel pump "ON." Reduce the speed during the flareout and contact the ground close to the stalling speed. After ground contact hold the nose wheel off as long as possible. As the airplane slows down, gently lower the nose and apply the brakes. Braking is most effective when flaps are raised and back pressure is applied to the control wheel, putting most of the aircraft weight on the main wheels. In high wind conditions, particularly in strong crosswinds, it may be desirable to approach the ground at higher than normal speeds with partial or no flaps.

#### 4.31 STOPPING ENGINE

At the pilot's discretion, the flaps should be raised and the electric fuel pump turned "OFF."

##### NOTE

The flaps must be placed in the "UP" position for the flap step to support weight. Passengers should be cautioned accordingly.

The air conditioner and radios should be turned "OFF," the propeller set in the full "INCREASE" position, and the engine stopped by disengaging the mixture control lock and pulling the mixture control back to idle cut-off. The throttle should be left full aft to avoid engine vibration while stopping. Then the magneto and master switches must be turned "OFF."

### **4.33 PARKING**

If necessary, the airplane should be moved on the ground with the aid of the nose wheel tow bar provided with each airplane and secured behind the rear seats. The aileron and stabilator controls should be secured by looping the safety belt through the control wheel and pulling it snug. The flaps are locked when in the "UP" position and should be left retracted.

Set the parking brake by pulling back on the brake lever and depressing the knob on the handle. To release the parking brake, pull back on the handle until the catch disengages; then allow the handle to swing forward.

#### **CAUTION**

Care should be taken when setting brakes that are overheated or during cold weather when accumulated moisture may freeze a brake.

Tie downs can be secured to rings provided under each wing and to the tail skid. The rudder is held in position by its connections to the nose wheel steering and normally does not have to be secured.

### **4.35 STALLS**

The stall characteristics of the Cherokee Arrow III are conventional. An approaching stall is indicated by a stall warning horn which is activated between five and ten knots above stall speed. Mild airframe buffeting and gentle pitching may also precede the stall.

The gross weight stalling speed of the Cherokee Arrow III with power off and full flaps is 55 KIAS. With the flaps up this speed is increased 5 KTS. Loss of altitude during stalls can be as great as 400 feet, depending on configuration and power.

#### **NOTE**

The stall warning system is inoperative with the master switch "OFF."

During preflight, the stall warning system should be checked by turning the master switch "ON," lifting the detector and checking to determine if the horn is actuated. The master switch should be returned to the "OFF" position after the check is complete.

### **4.37 TURBULENT AIR OPERATION**

In keeping with good operating practice used in all aircraft, it is recommended that when turbulent air is encountered or expected, the airspeed be reduced to maneuvering speed to reduce the structural loads caused by gusts and to allow for inadvertent speed build-ups which may occur as a result of the turbulence or of distractions caused by the conditions.

#### 4.39 LANDING GEAR

Some airplanes are equipped with an airspeed - power sensing system (backup gear extender) which extends the landing gear under low airspeed - power conditions\* even though the pilot may not have selected gear down. This system will also prevent retraction of the landing gear by normal means when the airspeed - power values are below a predetermined minimum. To override this system or to hold the emergency gear lever in the "OVERRIDE ENGAGED" position without maintaining manual pressure on the emergency gear lever, pull the lever full up and push the lock pin in. To release the override, pull lever up and then release. For normal operation, the pilot should extend and retract the gear with the gear selector switch located on the instrument panel, just as he would if the backup gear extender system were not installed.

The pilot should become familiar with the function and significance of the landing gear position indicators and warning lights.

The red gear warning light on the instrument panel and the horn operate simultaneously in flight when the throttle is reduced to where the manifold pressure is approximately 14 inches of mercury or below, and the gear selector switch is not in the "DOWN" position. On aircraft equipped with the backup gear extender, this warning will also occur during flight when the system has lowered the landing gear and the gear selector switch is not in the "DOWN" position and the manifold pressure is reduced below approximately 14 inches of mercury.

The red gear warning light on the instrument panel and the horn will also operate simultaneously on the ground when the master switch is "ON" and the gear selector switch is in the "UP" position and the throttle is in the retarded position.

The three green lights on the instrument panel operate individually as each associated gear is locked in the extended position.

#### WARNING

Panel lights' dimmer switch must be off to obtain gear lights full intensity during daytime flying. When aircraft is operated at night and panel lights' dimmer switch is turned on, gear lights will automatically dim.

On aircraft equipped with the backup gear extender, the yellow "Auto Ext. OFF" light immediately below the gear selector switch flashes whenever the emergency gear lever is in the "OVERRIDE ENGAGED" position.

When the Emergency Landing Gear Extension Procedure (paragraph 3.27) is performed for training purposes, the following changes must be made to the procedure in order to prevent the hydraulic pump from activating during the procedure. On aircraft equipped with the backup gear extender, the landing gear selector must be left in the UP position until all gear position indicators are green. On aircraft which do NOT have the backup gear extender, a pull type LANDING GEAR PUMP circuit breaker is installed and must be pulled prior to executing the emergency extension procedure. The circuit breaker must be reset after completion of the procedure to allow normal system operation.

#### 4.41 WEIGHT AND BALANCE

It is the responsibility of the owner and pilot to determine that the airplane remains within the allowable weight vs. center of gravity envelope while in flight.

For weight and balance data, refer to section 6 (Weight and Balance).

\*Approximately 95 KIAS at any altitude, power off.

TABLE OF CONTENTS

SECTION 5

PERFORMANCE

Paragraph No.		Page No.
5.1	General . . . . .	5-1
5.3	Introduction to Performance and Flight Planning . . . . .	5-1
5.5	Flight Planning Example . . . . .	5-3
5.7	Performance Graphs . . . . .	5-9
	List of Figures . . . . .	5-9



## 5.5 FLIGHT PLANNING EXAMPLE

### (a) Aircraft Loading

The first step in planning our flight is to calculate the airplane weight and center of gravity by utilizing the information provided by Section 6 (Weight and Balance) of this handbook.

The basic empty weight for the airplane as delivered from the factory has been entered in Figure 6-5. If any alterations to the airplane have been made effecting weight and balance, reference to the aircraft logbook and Weight and Balance Record (Figure 6-7) should be made to determine the current basic empty weight of the airplane.

Make use of the Weight and Balance Loading Form (Figure 6-11) and the C.G. Range and Weight graph (Figure 6-15) to determine the total weight of the airplane and the center of gravity position.

After proper utilization of the information provided we have found the following weights for consideration in our flight planning example.

The landing weight cannot be determined until the weight of the fuel to be used has been established refer to item (g)(1).

(1) Basic Empty Weight	1890 lbs.
(2) Occupants (2 x 170 lbs.)	340 lbs.
(3) Baggage and Cargo	70 lbs.
(4) Fuel (6 lb. x 50 gal.)	300 lbs.
(5) Takeoff Weight	2600 lbs.
(6) Landing Weight	
(a)(5) minus (g)(1), (2600 lbs. minus 62 lbs.)	2538 lbs.

Our takeoff weight is below the maximum of 2750 lbs. and our weight and balance calculations have determined our C.G. position within the approved limits.

### (b) Takeoff and Landing

Now that we have determined our aircraft loading, we must consider all aspects of our takeoff and landing.

All of the existing conditions at the departure and destination airport must be acquired, evaluated and maintained throughout the flight.

Apply the departure airport conditions and takeoff weight to the appropriate Takeoff Performance and Takeoff Ground Roll graph (Figures 5-5, 5-7, 5-9 and 5-11) to determine the length of runway necessary for the takeoff and/or the barrier distance.

The landing distance calculations are performed in the same manner using the existing conditions at the destination airport and, when established, the landing weight.

The conditions and calculations for our example flight are listed below. The takeoff and landing distances required for our example flight have fallen well below the available runway lengths.

	Departure Airport	Destination Airport
(1) Pressure Altitude	1900 ft.	1900 ft.
(2) Temperature	20°C	20°C
(3) Wind Component	4 KTS (Headwind)	2 KTS (Headwind)
(4) Runway Length Available	3000 ft.	4600 ft.
(5) Runway Required	2550 ft.*	1490 ft.**

NOTE

The remainder of the performance charts used in this flight plan example assume a no wind condition. The effect of winds aloft must be considered by the pilot when computing climb, cruise and descent performance.

(c) Climb

The next step in our flight plan is to determine the necessary climb segment components.

The desired cruise pressure altitude and corresponding cruise outside air temperature values are the first variables to be considered in determining the climb components from the Fuel, Time and Distance to Climb graph (Figure 5-17). After the fuel, time and distance for the cruise pressure altitude and outside air temperature values have been established, apply the existing conditions at the departure field to the graph (Figure 5-17). Now, subtract the values obtained from the graph for the field of departure conditions from those for the cruise pressure altitude.

The remaining values are the true fuel, time and distance components for the climb segment of the flight plan corrected for field pressure altitude and temperature.

The following values were determined from the above instructions in our flight planning example.

(1) Cruise Pressure Altitude	6000 ft.
(2) Cruise OAT	10°C
(3) Fuel to Climb (2 gal. minus 1 gal.)	2 gal.***
(4) Time to Climb (10 min. minus 3.5 min.)	6.5 min.***
(5) Distance to Climb (17 nautical miles minus 6 nautical miles)	11 nautical miles***

\*reference Figure 5-9

\*\*reference Figure 5-35

\*\*\*reference Figure 5-17

(d) Descent

The descent data will be determined prior to the cruise data to provide the descent distance for establishing the total cruise distance.

Utilizing the cruise pressure altitude and OAT we determine the basic fuel, time and distance for descent (Figure 5-31). These figures must be adjusted for the field pressure altitude and temperature at the destination airport. To find the necessary adjustment values, use the existing pressure altitude and temperature conditions at the destination airport as variables to find the fuel, time and distance values from the graph (Figure 5-31). Now, subtract the values obtained from the field conditions from the values obtained from the cruise conditions to find the true fuel, time and distance values needed for the flight plan.

The values obtained by proper utilization of the graphs for the descent segment of our example are shown below.

- |  |                    |
|--|--------------------|
| (1) Fuel to Descend (1.0 gal. minus 0.5 gal.)                      | 0.5 gal.*          |
| (2) Time to Descend (7 min. minus 3 min.)                          | 4 min.*            |
| (3) Distance to Descend (18 nautical miles minus 8 nautical miles) | 10 nautical miles* |

(e) Cruise

Using the total distance to be traveled during the flight, subtract the previously calculated distance to climb and distance to descend to establish the total cruise distance. Refer to the appropriate Avco Lycoming Operator's Manual and the Power Setting Table (Figure 5-19) when selecting the cruise power setting. The established pressure altitude and temperature values and the selected cruise power should now be utilized to determine the true airspeed from the appropriate Speed Power graph (Figure 5-21 or 5-23).

Calculate the cruise fuel flow for the cruise power setting from the information provided by the Avco Lycoming Operator's Manual.

The cruise time is found by dividing the cruise distance by the cruise speed and the cruise fuel is found by multiplying the cruise fuel flow by the cruise time.

The cruise calculations established for the cruise segment of our flight planning example are as follows:

- |   |                    |
|---|--------------------|
| (1) Total Distance  | 130 nautical miles |
| (2) Cruise Distance   |                    |
| (e)(1) minus (c)(4) minus (d)(2), (130 nautical miles<br>minus 11 nautical miles minus 10 nautical miles) | 109 nautical miles |
| (3) Cruise Power (Economy cruise)   | 65% rated power    |
| (4) Cruise Speed  | 129 KTS TAS**      |
| (5) Cruise Fuel Consumption   | 9.2 GPH            |
| (6) Cruise Time   |                    |
| (e)(2) divided by (e)(4), (109 nautical miles divided<br>by 129 KTS)                                      | .85 hrs. (51 min.) |
| (7) Cruise Fuel   |                    |
| (e)(5) multiplied by (e)(6), (9.2 GPH multiplied by .85 hrs.)   | 7.8 gal.           |

\*reference Figure 5-31

\*\*reference Figure 5-21

(f) Total Flight Time

The total flight time is determined by adding the time to climb, the time to descend and the cruise time. Remember! The time values taken from the climb and descent graphs are in minutes and must be converted to hours before adding them to the cruise time.

The following flight time is required for our flight planning example.

(1) Total Flight Time		
(c)(3) plus (d)(1) plus (e)(6), (.11 hrs. plus .07 hrs. plus .85 hrs.)		1.03 hrs.
(6.5 min. plus 4 min. plus 51 min.)		61.5 min.

(g) Total Fuel Required

Determine the total fuel required by adding the fuel to climb, the fuel to descend and the cruise fuel. When the total fuel (in gallons) is determined, multiply this value by 6 lb/gal to determine the total fuel weight used for the flight.

The total fuel calculations for our example flight plan are shown below.


(1) Total Fuel Required		
(c)(5) plus (d)(3) plus (e)(7), (2 gal. plus 0.5 gal. plus 7.8 gal.)		10.3 gal.
(10.3 gal. multiplied by 6 lb/gal.)		62 lbs.

5.7 PERFORMANCE GRAPHS

LIST OF FIGURES

Figure No.		Page No.
5-1	Airspeed System Calibration . . . . .	5-11
5-3	Power Off Stall Speed Versus Angle of Bank . . . . .	5-12
5-5	25° Flap Takeoff Performance Over 50 Foot Barrier . . . . .	5-13
5-7	25° Flap Takeoff Ground Roll . . . . .	5-14
5-9	0° Flap Takeoff Performance Over 50 Foot Barrier . . . . .	5-15
5-11	0° Flap Takeoff Ground Roll . . . . .	5-16
5-13	Gear Up Climb Performance . . . . .	5-17
5-15	Gear Down Climb Performance . . . . .	5-18
5-17	Fuel, Time and Distance to Climb . . . . .	5-19
5-19	Power Setting Table . . . . .	5-21
5-21	Speed Power - Performance Cruise . . . . .	5-23
5-23	Speed Power - Economy Cruise . . . . .	5-24
5-25	Range - Best Power . . . . .	5-25
5-27	Range - Best Economy . . . . .	5-26
5-29	Endurance . . . . .	5-27
5-31	Fuel, Time and Distance to Descend . . . . .	5-28
5-33	Glide Time and Distance . . . . .	5-29
5-35	Landing Distance Over 50 Foot Barrier . . . . .	5-30
5-37	Landing Ground Roll Distance . . . . .	5-31


# PA-28R-201



AIRSPEED CALIBRATION

Figure 5-1


# PA-28R-201



POWER OFF STALL SPEED VERSUS ANGLE OF BANK

Figure 5-3

# PA-28R-201



**Example:**


- Pressure altitude: 1900 ft.
- Outside air temperature: 20°C
- Weight: 2600 lbs.
- Surface wind: 4 kts. (headwind)
- Liftoff speed: 57 KIAS
- Speed at 50 ft.: 60 KIAS
- Takeoff distance: 1850 ft.

**25° FLAP TAKEOFF PERFORMANCE OVER 50 FOOT BARRIER**

Figure 5-5



# PA-28R-201




**Example:**

- Pressure altitude: 1900 ft.
- Outside air temperature: 20°C
- Weight: 2600 lbs.
- Surface wind: 4 kts. (headwind)
- Lift-off speed: 57 KIAS
- Takeoff ground roll: 1125 ft.

**25° FLAP TAKEOFF GROUND ROLL**

Figure 5-7

# PA-28R-201




**Example:**

- Pressure altitude: 1900 ft.
- Outside air temperature: 20°C
- Weight: 2600 lbs.
- Surface wind: 4 kts. (headwind)
- Liftoff speed: 69 KIAS
- Speed at 50 ft.: 69 KIAS
- Takeoff distance: 2550 ft.

**0° FLAP TAKEOFF DISTANCE OVER 50 FOOT BARRIER**

Figure 5-9

# PA-28R-201




**Example:**

- Pressure altitude: 1900 ft.
- Outside air temperature: 20°C
- Weight: 2600 lbs.
- Surface wind: 4 kts. (headwind)
- Lift-off speed: 66 KIAS
- Takeoff ground roll: 1950 ft.

**0° FLAP TAKEOFF GROUND ROLL**

Figure 5-11

# PA-28R-201




**Example:**

Climb pressure altitude: 6000 ft.  
Outside air temperature: 10°C  
Weight: 2750 lbs.  
Rate of climb: 510 F.P.M.

### GEAR UP CLIMB PERFORMANCE

Figure 5-13

# PA-28R-201




**Example:**

Climb pressure altitude: 6000 ft.  
 Outside air temperature: 10°C  
 Rate of climb: 240 F.P.M.

**GEAR DOWN CLIMB PERFORMANCE**

Figure 5-15

# PA-28R-201



**Example:**

Departure pressure altitude: 1900 ft.  
 Departure outside air temperature: 20 °C  
 Cruise pressure altitude: 6000 ft.  
 Cruise outside air temperature: 10 °C  
 Fuel to climb: 3 gal. minus 1 gal. = 2 gal.  
 Time to climb: 10 min. minus 3.5 min. = 6.5 min.  
 Distance to climb: 17 naut. mi. minus 6 naut. mi. = 11 naut. mi.

**FUEL, TIME AND DISTANCE TO CLIMB**

Figure 5-17

**Power Setting Table - Lycoming Model IO-360-C Series, 200 HP Engine**

Press. Alt Feet	Std. Alt Temp ° F	110 HP - 55% Rated		130 HP - 65% Rated		150 HP - 75% Rated		Press. Alt Feet
		RPM 2100	MAN. PRESS. 2400	RPM 2100	MAN. PRESS. 2400	RPM 2400	MAN. PRESS. 2400	
SL	59	22.9	20.4	25.9	22.9	25.5	25.5	SL
1,000	55	22.7	20.2	25.6	22.7	25.2	25.2	1,000
2,000	52	22.4	20.0	25.4	22.5	25.0	25.0	2,000
3,000	48	22.2	19.8	25.1	22.2	24.7	24.7	3,000
4,000	45	21.9	19.5	24.8	22.0	24.4	24.4	4,000
5,000	41	21.7	19.3	FT	21.7	FT	FT	5,000
6,000	38	21.4	19.1	---	21.5	---	---	6,000
7,000	34	21.2	18.9	---	21.3	---	---	7,000
8,000	31	21.0	18.7	---	21.0	---	---	8,000
9,000	27	FT	18.5	---	FT	---	---	9,000
10,000	23	---	18.3	---	---	---	---	10,000
11,000	19	---	18.1	---	---	---	---	11,000
12,000	16	---	17.8	---	---	---	---	12,000
13,000	12	---	17.6	---	---	---	---	13,000
14,000	9	---	FT	---	---	---	---	14,000


**POWER SETTING TABLE**

Figure 5-19

To maintain constant power, correct manifold pressure approximately 0.16" Hg for each 10° F variation in inlet air temperature from standard altitude temperature. Add manifold pressure for air temperatures above standard; subtract for temperatures below standard.

Full throttle manifold pressure values may not be obtainable when atmospheric conditions are non-standard.

# PA-28R-201



*55% @ 115 kts  
 65% @ 130 kts*

**Example:**


- Cruise pressure altitude: 6000 ft.
- Cruise outside air temperature: 10°C
- Power: 65%
- Cruise speed: 134 kts.

**SPEED POWER - PERFORMANCE CRUISE**

Figure 5-21



# PA-28R-201




**Example:**

Cruise pressure altitude: 6000 ft.  
 Cruise outside air temperature: 10°C  
 Power: 65%  
 Cruise speed: 129 kts.

**SPEED POWER - ECONOMY CRUISE**

Figure 5-23

# PA-28R-201




Example:  
 Cruise pressure altitude: 6000 ft.  
 Cruise outside air temperature: 10°C  
 Power: 65%  
 Range: 755 naut. mi. with reserve  
 840 naut. mi. without reserve

RANGE - BEST POWER

Figure 5-25

# PA-28R-201




**Example:**

Cruise pressure altitude: 6000 ft.  
Cruise outside air temperature: 10°C  
Power: 65%  
Range: 835 naut. mi. with reserve  
935 naut. mi. without reserve

**RANGE - BEST ECONOMY**

Figure 5-27

# PA-28R-201




**Example:**

- Cruise pressure altitude: 6000 ft.
- Cruise outside air temperature: 10°C
- Power: 65%
- Endurance: 6.5 hours with reserve  
7.2 hours without reserve

**ENDURANCE**

Figure 5-29

# PA-28R-201



**Example:**

Cruise pressure altitude: 6000 ft.

Cruise outside air temperature: 10°C

Destination pressure altitude: 1900 ft.

Destination outside air temperature: 20°C

Fuel to descend: 1.0 gal. minus .5 gal. = .5 gal.


Time to descend: 7 min. minus 3 min. = 4 min.

Distance to descend: 18 naut. mi. minus 8 naut. mi. = 10 naut. mi.

**FUEL, TIME AND DISTANCE TO DESCEND**

Figure 5-31

# PA-28R-201



*• 1.8 nm/1KFT*

**Example:**

- Cruise pressure altitude: 6000 ft.
- Cruise outside air temperature: 10 °C
- Terrain pressure altitude: 2000 ft.
- Terrain outside air temperature: 20 °C
- Glide time: 7.5 min. minus 3.5 min. = 4 min.
- Glide distance: 11 naut. mi. minus 5 naut. mi. = 6 naut. mi.

**GLIDE TIME AND DISTANCE**

Figure 5-33

TABLE OF CONTENTS

SECTION 6

WEIGHT AND BALANCE

Paragraph No.		Page No.
6.1	General . . . . .	6-1
6.3	Airplane Weighing Procedure . . . . .	6-3
6.5	Weight and Balance Data and Record . . . . .	6-6
6.7	Weight and Balance Determination for Flight . . . . .	6-11
6.9	Equipment list	
	Additional Equipment list	
	Propeller	
	Avionics	

SECTION 6  
WEIGHT AND BALANCE

6.1 GENERAL

In order to achieve the performance and flying characteristics which are designed into the airplane, it must be flown with the weight and center of gravity (C.G.) position within the approved operating range (envelope). Although the airplane offers flexibility in loading, it cannot be flown with the maximum number of adult passengers, full fuel tanks and maximum baggage. With the flexibility comes responsibility. The pilot must ensure that the airplane is loaded within the loading envelope before he makes a takeoff.

Misloading carries consequences for any aircraft. An overloaded airplane will not take off, climb or cruise as well as a properly loaded one. The heavier the airplane is loaded, the less climb performance it will have.

Center of gravity is a determining factor in flight characteristics. If the C.G. is too far forward in any airplane, it may be difficult to rotate for takeoff or landing. If the C.G. is too far aft, the airplane may rotate prematurely on takeoff or tend to pitch up during climb. Longitudinal stability will be reduced. This can lead to inadvertent stalls and even spins; and spin recovery becomes more difficult as the center of gravity moves aft of the approved limit.

A properly loaded airplane, however, will perform as intended. Before the airplane is licensed, a basic empty weight and C.G. location is computed (basic empty weight consists of the standard empty weight of the airplane plus the optional equipment). Using the basic empty weight and C.G. location, the pilot can easily determine the weight and C.G. position for the loaded airplane by computing the total weight and moment and then determining whether they are within the approved envelope.

The basic empty weight and C.G. location are recorded in the Weight and Balance Data Form (Figure 6-5) and the Weight and Balance Record (Figure 6-7). The current values should always be used. Whenever new equipment is added or any modification work is done, the mechanic responsible for the work is required to compute a new basic empty weight and C.G. position and to write these in the Aircraft Log Book and the Weight and Balance Record. The owner should make sure that it is done.

A weight and balance calculation is necessary in determining how much fuel or baggage can be boarded so as to keep within allowable limits. Check calculations prior to adding fuel to insure against improper loading.

The following pages are forms used in weighing an airplane in production and in computing basic empty weight, C.G. position, and useful load. Note that the useful load includes usable fuel, baggage, cargo and passengers. Following this is the method for computing takeoff weight and C.G.



### 6.3 AIRPLANE WEIGHING PROCEDURE

At the time of licensing, Piper Aircraft Corporation provides each airplane with the basic empty weight and center of gravity location. This data is supplied by Figure 6-5.

The removal or addition of equipment or airplane modifications can affect the basic empty weight and center of gravity. The following is a weighing procedure to determine this basic empty weight and center of gravity location:

(a) Preparation

- (1) Be certain that all items checked in the airplane equipment list are installed in the proper location in the airplane.
- (2) Remove excessive dirt, grease, moisture, foreign items such as rags and tools from the airplane before weighing.
- (3) Defuel airplane. Then open all fuel drains until all remaining fuel is drained. Operate engine on each tank until all undrainable fuel is used and engine stops. Then add the unusable fuel (5.0 gallons total, 2.5 gallons each wing).

#### CAUTION

Whenever the fuel system is completely drained and fuel is replenished it will be necessary to run the engine for a minimum of three minutes at 1000 RPM on each tank to insure that no air exists in the fuel supply lines.

- (4) Fill with oil to full capacity.
  - (5) Place pilot and copilot seats in fourth (4th) notch, aft of forward position. Put flaps in the fully retracted position and all control surfaces in the neutral position. Tow bar should be in the proper location and all entrance and baggage doors closed.
  - (6) Weigh the airplane inside a closed building to prevent errors in scale readings due to wind.
- (b) Leveling
- (1) With airplane on scales, block main gear oleo pistons in the fully extended position.
  - (2) Level airplane (refer to Figure 6-3) deflating nose wheel tire, to center bubble on level.

(c) Weighing - Airplane Basic Empty Weight

- (1) With the airplane level and brakes released, record the weight shown on each scale. Deduct the tare, if any, from each reading.


Scale Position and Symbol	Scale Reading	Tare	Net Weight
Nose Wheel (N)			
Right Main Wheel (R)			
Left Main Wheel (L)			
Basic Empty Weight, as Weighed (T)	— —	— —	

WEIGHING FORM

Figure 6-1

(d) Basic Empty Weight Center of Gravity

- (1) The following geometry applies to the PA-28R-201 airplane when it is level. Refer to Leveling paragraph 6.3 (b).



LEVELING DIAGRAM

Figure 6-3

- (2) The basic empty weight center of gravity (as weighed including optional equipment, full oil and unusable fuel) can be determined by the following formula:

$$\text{C.G. Arm} = \frac{N(A) + (R + L)(B)}{T} \text{ inches}$$

Where:  $T = N + R + L$

**6.5 WEIGHT AND BALANCE DATA AND RECORD**

The Basic Empty Weight, Center of Gravity Location and Useful Load listed in Figure 6-5 are for the airplane as licensed at the factory. These figures apply only to the specific airplane serial number and registration number shown.

The basic empty weight of the airplane as licensed at the factory has been entered in the Weight and Balance Record (Figure 6-7). This form is provided to present the current status of the airplane basic empty weight and a complete history of previous modifications. Any change to the permanently installed equipment or modification which affects weight or moment must be entered in the Weight and Balance Record.

MODEL PA-28R-201 CHEROKEE ARROW III

Airplane Serial Number \_\_\_\_\_

Registration Number \_\_\_\_\_

Date \_\_\_\_\_

AIRPLANE BASIC EMPTY WEIGHT

Item	Weight (Lbs)		x	C. G. Arm (Inches Aft of Datum)	=	Moment (In-Lbs)
	Actual	Computed				
Standard Empty Weight*						
Optional Equipment						
Basic Empty Weight						

\*The standard empty weight includes full oil capacity and 5.0 gallons of unusable fuel.

AIRPLANE USEFUL LOAD - NORMAL CATEGORY OPERATION

(Gross Weight) - (Basic Empty Weight) = Useful Load

(2750 lbs) - (        lbs) =        lbs.

THIS BASIC EMPTY WEIGHT, C.G. AND USEFUL LOAD ARE FOR THE AIRPLANE AS LICENSED AT THE FACTORY. REFER TO APPROPRIATE AIRCRAFT RECORD WHEN ALTERATIONS HAVE BEEN MADE.

WEIGHT AND BALANCE DATA FORM

Figure 6-5

PA-28R-201	Date	Item No.		Serial Number	Registration Number					Page Number		
		In	Out		Weight Change			Running Basic Empty Weight				
			Description of Article or Modification		Added (+)		Removed (-)		Wt. (Lb.)	Moment /100		
				As Licensed	Wt. (Lb.)	Arm (In.)	Moment /100	Wt. (Lb.)	Arm (In.)	Moment /100	Wt. (Lb.)	Moment /100

WEIGHT AND BALANCE RECORD  
 Figure 6-7

**SECTION 6  
WEIGHT AND BALANCE**

**PIPER AIRCRAFT CORPORATION  
PA-28R-201, CHEROKEE ARROW III**

PA-28R-201	Serial Number		Registration Number	Page Number	
	Date	Item No. In      Out		Weight Change	Running Basic Empty Weight
Description of Article or Modification		Removed (-)			
		Wt. (Lb.)	Arm (In.)	Moment /100	Wt. (Lb.)
					Moment /100

**WEIGHT AND BALANCE RECORD (cont)**  
Figure 6-7 (cont)

6.7 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT

- (a) Add the weight of all items to be loaded to the basic empty weight.
- (b) Use the Loading Graph (Figure 6-13) to determine the moment of all items to be carried in the airplane.
- (c) Add the moment of all items to be loaded to the basic empty weight moment.
- (d) Divide the total moment by the total weight to determine the C.G. location.
- (e) By using the figures of item (a) and item (d) (above), locate a point on the C.G. range and weight graph (Figure 6-15). If the point falls within the C.G. envelope, the loading meets the weight and balance requirements.

	Weight (Lbs)	Arm Aft Datum (Inches)	Moment (In-Lbs)
Basic Empty Weight			
Pilot and Front Passenger	340.0	80.5	27370
Passengers (Rear Seats)	340.0	118.1	40154
Fuel (72 Gallon Maximum)		95.0	
Baggage		142.8	
Moment due to Retraction of Landing Gear			819
Total Loaded Airplane			

The center of gravity (C.G.) of this sample loading problem is at \_\_\_\_\_ inches aft of the datum line. Locate this point ( \_\_\_\_\_ ) on the C.G. range and weight graph. Since this point falls within the weight - C.G. envelope, this loading meets the weight and balance requirements.

IT IS THE RESPONSIBILITY OF THE PILOT AND AIRCRAFT OWNER TO INSURE THAT THE AIRPLANE IS LOADED PROPERLY.

SAMPLE LOADING PROBLEM (NORMAL CATEGORY)

Figure 6-9



**SECTION 6  
WEIGHT AND BALANCE**


**PIPER AIRCRAFT CORPORATION  
PA-28R-201, CHEROKEE ARROW III**

	Weight (Lbs)	Arm Aft Datum (Inches)	Moment (In-Lbs)
Basic Empty Weight			
Pilot and Front Passenger		80.5	
Passengers (Rear Seats)		118.1	
Fuel (72 Gallon Maximum)		95.0	
Baggage		142.8	
Moment due to Retraction of Landing Gear			819
Total Loaded Airplane			

Totals must be within approved weight and C.G. limits. It is the responsibility of the airplane owner and the pilot to insure that the airplane is loaded properly. The Basic Empty Weight C.G. is noted on the Weight and Balance Data Form (Figure 6-5). If the airplane has been altered, refer to the Weight and Balance Record for this information.


**WEIGHT AND BALANCE LOADING FORM**

Figure 6-11



LOADING GRAPH

Figure 6-13



Moment due to retracting landing gear = +819 in. lbs.

C. G. RANGE AND WEIGHT

Figure 6-15

6.9 EQUIPMENT LIST

The following is a list of equipment which may be installed in the PA-28R-201. It consists of those items used for defining the configuration of an airplane when the basic empty weight is established at the time of delivery. Only those standard items which are alternate standard items and those required to be listed by the certificating authority (FAA) are presented. Items marked with an "X" are those items which were installed on the airplane described below as delivered by the manufacturer.

PIPER AIRCRAFT CORPORATION

PA-28R-201 CHEROKEE ARROW III

SERIAL NO. 28R-7837292 REGISTRATION NO. N36777 DATE: 6-23-78

(a) Propeller and Propeller Accessories

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
1	<i>add</i> Propeller, McCauley B3D36C424/745A <del>(including spinner 6012-1)</del> <u>X</u>	<u>X</u>	71.3	-2.0	-142.6
	a. Propeller, McCauley B2D34C213/90DHA-16 <del>Removed</del>	<del>X</del> <i>Removed</i>	49.0	-1.9	-93
	Cert. Basis - TC P7EA				
2	b. Propeller, Hartzell HC-C2YK-1( )F/ F7666A-2R		55.0	-1.9	-105
	Cert. Basis - TC P920				
	a. Spinner and Attachment Plate Installation PAC Dwg. 35828-2 (For McCauley Prop.) <del>Removed</del>	<del>X</del> <i>Removed</i>	4.7	-2.2	-10
3	b. Spinner and Attachment Plate Installation PAC Dwg. 99374 (For Hartzell Prop.)		5.0	-2.2	-11
	Cert. Basis - TC 2A13				
3	Propeller Governor Hartzell Model F-2-7 ( )				
	Cert. Basis - TC P7EA				

(j) Electrical Equipment  
(Optional Equipment)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
79	Instrument Panel Lights Cert. Basis - TC 2A13	X _____	0.3	62.8	19
81	Instrument Light, Grimes 15-0083-7 Cert. Basis - TC 2A13	X _____	0.1	99.0	10
83	Cabin Light Cert. Basis - TC 2A13	X _____	0.3	99.0	30
85	Landing Light, G.E. Model 4509 Cert. Basis - TC 2A13	X _____	0.5	10.0	5
87	Navigation Lights (Wing) (2) Grimes Model A1285 (Red) and Green) Cert. Basis - TC 2A13	_____ _____	0.4	106.6	43
89	Navigation Light (Rear) (1), Grimes Model A2064 (White) Cert. Basis - TC 2A13	X _____	0.2	281.0	56
91	Rotating Beacon Cert. Basis - TC 2A13	X _____	1.5	263.4	395
93	Anti-Collision Lights (Wing Tip) (Whelen) Cert. Basis - STC SA615EA	X _____	5.7	157.9	900
95	Heated Pitot Head, Cert. Basis - TC 2A13	X _____	0.4	100.0	40
97	Piper Pitch Trim Piper Dwg. 67496-3 Cert. Basis - TC 2A13	_____ _____	4.3	155.3	668
99	Battery 12V 35 A.H. Rebat R35 (Wt. 27.2 lbs.) Cert. Basis - TC 2A13	X _____	*5.3	168.0	890

\*Weight and moment difference between standard and optional equipment.

**Congressional Air Charters, Inc.**  
**7940 Airpark Road**  
**Gaithersburg, MD 20879**

Tel: 301-840-0880  
 Fax: 301-926-2340

**AIRCRAFT:** Owner Linda Litwin Address 3803 Legation St. NW  
 Make PA28R-201 Washington DC.  
 Model Arrow III 20015  
 Serial # 28R-7837292  
 N Number N36777 Date 10/26/99

**PREVIOUS:** Empty Weight 1740.9  
 Useful Load 1009.1  
 Empty Weight C.G. 84.52

NEW WEIGHT AND BALANCE DATA

<u>ITEM:</u>	<u>WEIGHT</u>	<u>ARM</u>	<u>MOMENT</u>
<u>Previous</u>	1740.9	84.52	147148.8
<u>Removed</u> McCauley two blade propeller and spinner assy.	53.7	-2.0	-107.4
<u>Installed</u> New 3 Blade McCauley propeller and spinner assy.	71.3 lb.	-2.0	-142.6

**REVISED/NEW:**

EMPTY WEIGHT	<u>1758.5</u>
USEFUL LOAD	<u>991.5</u>
EMPTY WEIGHT C.G.	<u>83.66</u>

**Signature** Michael W. Wickham III APZ13508270



Frederick Aviation, Inc.  
 330 Aviation Way Municipal Airport  
 Frederick, Maryland 21701

## Frederick Aviation Inc. - Repair Station LC1R291K

### Additional Equipment List and C.G. Range and Weight and Balance Data

Registration Number N36777  
 Aircraft Serial Number 28R-7837292  
 Date June 22, 2006  
 Work order number 1006617

Previous Calculations: By Congressional Air, 10/26/99 1758.50 83.66 147113.60

<u>Item</u>	<u>P/N</u>	<u>S/N</u>	<u>Weight</u>	<u>Arm</u>	<u>Moment</u>
<b>Items Removed</b>					
Narco AT-150 Transponder		14162	-3.00	57.300	-171.90
<b>Items Installed</b>					
Garmin GTX-327 Transponder	011-00490-00	83724725	3.03	59.300	179.68
Halon Fire Extinguisher & Bracket	RTA400	V-175585	1.47	97.000	142.59

New Calculations: 1760.00 83.67 147263.97

New Aircraft Empty Weight 1760.00  
 Aircraft Empty Weight C.G. 83.67  
 Aircraft Useful Load (Normal) 990.00  
 (Utility) \_\_\_\_\_  
 Aircraft Gross Weight 2750

\*\*\*\*\*  
 It is the responsibility of the pilot and the aircraft owner to insure that the airplane is loaded properly. Refer to loading graphs and C.G. range and weights graph if applicable to this aircraft. See aircraft weight and balance data.  
 \*\*\*\*\*

Technician Jan B. Randolph Inspector [Signature]

TABLE OF CONTENTS

SECTION 7

DESCRIPTION AND OPERATION  
OF THE AIRPLANE AND ITS SYSTEMS

Paragraph No.		Page No.
7.1	The Airplane . . . . .	7-1
7.3	Airframe . . . . .	7-1
7.5	Engine and Propeller . . . . .	7-3
7.7	Induction System . . . . .	7-3
7.9	Engine Controls . . . . .	7-4
7.11	Landing Gear . . . . .	7-6
7.13	Flight Controls . . . . .	7-10
7.15	Fuel System . . . . .	7-13
7.17	Electrical System . . . . .	7-15
7.19	Vacuum System . . . . .	7-18
7.21	Pitot-Static System . . . . .	7-18
7.23	Instrument Panel . . . . .	7-21
7.25	Cabin Features . . . . .	7-22
7.27	Baggage Area . . . . .	7-25
7.29	Heating and Ventilating System . . . . .	7-25
7.31	Stall Warning . . . . .	7-25
7.33	Finish . . . . .	7-25
7.35	Air Conditioning . . . . .	7-26
7.37	Piper External Power . . . . .	7-27
7.39	Emergency Locator Transmitter . . . . .	7-27



## SECTION 7

### DESCRIPTION AND OPERATION OF THE AIRPLANE AND ITS SYSTEMS

#### 7.1 THE AIRPLANE

The Cherokee Arrow III is a single engine, retractable landing gear, all metal airplane. It has seating for up to four occupants and has a 200 pound luggage compartment.

#### 7.3 AIRFRAME

With the exception of the steel engine mount, the landing gear, miscellaneous steel parts, the cowling, and the lightweight plastic extremities (tips of wings, tail fin, rudder and stabilator), the basic airframe is of aluminum alloy. Aerobatics are prohibited in this airplane since the structure is not designed for aerobatic loads.

The fuselage is a semi-monocoque structure with a passenger door on the forward right hand side and a cargo door on the aft right hand side.

The wing is of a semitapered design and employs a laminar flow NACA 65<sub>2</sub>-415 airfoil section. The main spar is located at approximately 40% of the chord aft of the leading edge. The wings are attached to the fuselage by the insertion of the butt ends of the spar into a spar box carry-through, which is an integral part of the fuselage structure. The bolting of the spar ends into the spar box carry-through structure, which is located under the aft seats, provides in effect a continuous main spar. The wings are also attached fore and aft of the main spar by an auxiliary front spar and a rear spar. The rear spar, in addition to taking torque and drag loads, provides a mount for flaps and ailerons. The four-position wing flaps are mechanically controlled by a handle located between the front seats. When fully retracted, the right flap locks into place to provide a step for cabin entry. Each wing contains one fuel tank.

A vertical stabilizer, an all-movable horizontal stabilator, and a rudder make up the empennage. The stabilator incorporates an anti-servo tab which improves longitudinal stability and provides longitudinal trim. This tab moves in the same direction as the stabilator, but with increased travel.

## 7.5 ENGINE AND PROPELLER

The Cherokee Arrow III incorporates a Lycoming IO-360-C1C6 four-cylinder, direct drive, horizontally opposed fuel injected engine rated at 200 horsepower at 2700 RPM. It is furnished with a starter, 60 ampere 14-volt alternator, shielded ignition, vacuum pump drive, fuel pump, propeller governor and a dry automotive type induction air filter. A recommended overhaul period is based on Lycoming service experience. Since Lycoming from time to time revises the recommended overhaul period, the owner should check the latest Lycoming Service Instruction Number 1009 at his Piper dealer for the latest recommended overhaul period and for any additional information.

The aircraft is equipped with a constant speed, controllable pitch propeller. The propeller control is located on the power quadrant between the throttle and mixture controls. A mixture control lock is provided to prevent activation of the mixture control instead of the pitch control.

The exhaust system is a crossover type, which reduces back pressure and improves performance. It is constructed entirely of stainless steel and is equipped with dual mufflers. Cabin heat and windshield defrosting are provided by a heater shroud around the muffler.

An oil cooler is located on the forward lower right side of the firewall, with the air inlet for the cooler located on the right side of the bottom cowling. A winterization plate is provided to restrict air during winter operation. (See Winterization in Handling and Servicing.)

## 7.7 INDUCTION SYSTEM

The induction system incorporates a Bendix RSA-5AD1 type fuel injector. The injector is based on the principle of differential pressure, which balances air pressure against fuel pressure. The regulated fuel pressure established by the servo valve when applied across a fuel control (jetting system) makes the fuel flow proportional to airflow. Fuel pressure regulation by the servo valve causes a minimal drop in fuel pressure throughout the metering system. Metering pressure is maintained above most vapor forming conditions while fuel inlet pressure is low enough to allow use of a diaphragm pump. The servo system feature also checks vapor lock and associated starting problems.

The servo regulation meters fuel flow proportionally with airflow and maintains the mixture as manually set for all engine speeds. The fuel flow divider receives metered fuel and distributes fuel to each cylinder fuel nozzle.

The fuel flow portion of the manifold fuel flow gauge is connected to the flow divider and monitors fuel pressure. This instrument converts fuel pressure to an indication of fuel flow in gallons per hour and percentage of rated horsepower.

✓ The alternate air source of the induction system contains a door that functions automatically or manually. If the primary source is obstructed, the door will open automatically. It may be opened manually by moving the selector on the right side of the quadrant. The primary source should always be used for take-off.

The pilot should read and follow the procedures recommended in the Lycoming Operator's Manual for this engine, in order to obtain maximum engine efficiency and time between engine overhauls.

### **7.9 ENGINE CONTROLS**

Engine controls consist of a throttle control, a propeller control and a mixture control lever. These controls are located on the control quadrant on the lower center of the instrument panel (Figure 7-1) where they are accessible to both the pilot and the copilot. The controls utilize teflon-lined control cables to reduce friction and binding.

The throttle lever is used to adjust the manifold pressure. It incorporates a gear up warning horn switch which is activated during the last portion of travel of the throttle lever to the low power position. If the landing gear is not locked down, the horn will sound until the gear is down and locked or until the power setting is increased. This is a safety feature to prevent an inadvertent gear up landing. ✓


The propeller control lever is used to adjust the propeller speed from high RPM to low RPM.

The mixture control lever is used to adjust the air to fuel ratio. The engine is shut down by the placing of the mixture control lever in the full lean position. In addition, the mixture control has a lock to prevent activation of the mixture control instead of the pitch control. For information on the leaning procedure, see the Avco-Lycoming Operator's Manual.

The friction adjustment lever on the right side of the control quadrant may be adjusted to increase or decrease the friction holding the throttle, propeller, and mixture controls in a selected position.


The alternate air control is located to the right of the control quadrant. When the alternate air lever is in the up, or closed, position the engine is operating on filtered air; when the lever is in the down, or open, position the engine is operating on unfiltered, heated air (refer to Figure 7-1). ✓

*B/O GEAR EXTENDED  
THROTTLE GEAR UP WARN HORN  
SPRING LOADED TO GEAR UP*



CONTROL QUADRANT AND CONSOLE

Figure 7-1



LANDING GEAR SELECTOR

Figure 7-3

### 7.11 LANDING GEAR

The Cherokee Arrow III is equipped with a retractable tricycle landing gear, which is hydraulically actuated by an electrically powered reversible pump. The pump is controlled by a selector switch on the instrument panel to the left of the control quadrant (figure 7-3). The landing gear is retracted or extended in about seven seconds. 7 sec

Some aircraft also incorporate a pressure sensing device in the system which lowers the gear regardless of gear selector position, depending upon airspeed and engine power (propeller slipstream). Gear extension is designed to occur, even if the selector is in the up position, at airspeeds below approximately 95 KIAS with power off. The extension speeds will vary from approximately 75 KTS to approximately 95 KIAS depending on power settings and altitude. The device also prevents the gear from retracting at airspeeds below approximately 75 KTS with full power, though the selector switch may be in the up position. This speed increases with reduced power and/or increased altitude. Manual override of the device is provided by an emergency gear lever located between the front seats to the left of the flap handle (refer to figure 7-9). The sensing device operation is controlled by differential air pressure across a flexible diaphragm which is mechanically linked to a hydraulic valve and an electrical switch which actuates the pump motor. A high pressure and static air source for actuating the diaphragm is provided in a mast mounted on the left side of the fuselage above the wing. Any obstruction of the holes in this mast will cause the gear to extend. An optional heated mast is available to alleviate obstruction in icing conditions. The optional heated mast is turned on whenever the "PITOT HEAT" is turned on.

### WARNING

Avoid ejecting objects out of the pilot storm window which could possible enter or obstruct the holes in the mast.

✓ The emergency gear lever, when placed in the raised position, can be used to override the system, and gear position is then controlled by the selector switch regardless of airspeed/power combinations. The emergency gear lever is provided with a locking device which may be used to lock the override lever in the up position. The lock is located on the left side panel of the console below the level of the manual override lever. To lock the override lever in the up position, raise the override lever to the full up position and push the lock pin in. A yellow warning light located below the gear selector switch (figure 7-3) flashed to warn the pilot that the automatic gear lowering system is disabled. The lock is spring-loaded to the off position to aid disengagement. To disengage the lock raise the override lever and release. The lever will return to its normal position and the yellow flashing light will extinguish. The lever must also be locked in the raised (up) position when gear-up stalls are practiced.

✓ The emergency gear lever, when used for emergency extension of the gear, <sup>(mechanically)</sup> manually releases hydraulic pressure to permit the gear to free-fall with spring assistance on the nose gear. The lever must be held in the downward position for emergency extension.

Gear down and locked positions are indicated by three green lights located below the selector, and a red "Warning Gear Unsafe" light is located at the top of the panel. An all lights out condition indicates the gear is up. The landing gear should not be retracted above a speed of 107 KIAS and should not be extended above a speed of 129 KIAS.

The main landing gear uses 6.00 x 6 wheels. The main gear incorporate brake drums and single disc hydraulic brake assemblies. The nose wheel carries a 5.00 x 5 four ply tire and the main gear use 6.00 x 6 six ply tires. All three tires are tube type.

A micro switch in the throttle quadrant activates a warning horn and red "Warning Gear Unsafe" light under the following conditions:

- (a) Gear up and power reduced below approximately 14 inches of manifold pressure.
- (b) On aircraft equipped with the backup gear extender, if the system has extended the landing gear and the gear extender is "UP," with the power reduced below approximately 14 inches of manifold pressure.
- (c) Gear selector switch "UP" while on the ground and throttle in retarded position.


On aircraft which are NOT equipped with the backup gear extender, an additional switch is installed which activates the warning horn and light and flaps are extended beyond the approach position (10°) and the landing gear are not down and locked.

✓ The gear warning horn emits a 90 Hz beeping sound in contrast to the stall warning horn which emits a continuous sound.

The nose gear is steerable through a 30 degree arc each side of center through the use of the rudder pedals. As the nose wheel retracts, the steering linkage disengages to reduce rudder pedal loads in flight. The nose wheel is equipped with a hydraulic shimmy dampener to reduce nose wheel shimmy. A bungee assembly is also included to reduce ground steering effort and to dampen shocks and bumps during taxiing.

The oleo strut are of the air-oil type, with normal extension being 2.75 +/- 0.25 inches for the nose gear and 2.5 +/- 0.25 inches for the main gear under normal static load (empty weight of airplane plus full fuel and oil).

The standard brake system includes toe brakes on the left and right set of rudder pedals and a hand brake located below and near the center of the instrument panel. The toe brakes and the hand brake have individual brake cylinders, but all cylinders use a common reservoir. The parking brake is incorporated in the lever brake and is operated by pulling back on the lever and depressing the knob attached to the top of the handle. To release the parking brake, pull back on the brake lever; then allow the handle to swing forward.



FLIGHT CONTROL CONSOLE

Figure 7-9

### 7.13 FLIGHT CONTROLS

Dual flight controls are provided as standard equipment. A cable system provides actuation of the control surfaces when the flight controls are moved in their respective directions.

The horizontal surface (stabilator) is of the flying tail design with a trim tab/servo mounted on the trailing edge. This tab serves the dual function of providing trim control and pitch control forces. The trim function is controlled by a trim control wheel located on the control console between the two front seats (figure 7-9). Rotating the wheel forward gives nose down trim and rotation aft gives nose up trim.

The rudder is conventional in design and incorporates a rudder trim. The trim mechanism is a spring-loaded recentering device. The trim control is located on the right side of the pedestal below the throttle quadrant. Turning the trim control clockwise gives nose right trim and counterclockwise rotation gives nose left trim.


Manually controlled flaps are provided. They are extended by a control cable and are spring-loaded to the retracted (up) position. The control is located between the two front seats on the control console. To extend the flaps pull the handle up to the desired flap setting of 10, 25 or 40 degrees. To retract, depress the button on the end of the handle and lower the control.

When extending or retracting flaps, there is a pitch change in the aircraft. This pitch change can be corrected either by stabilator trim or increased control wheel force. When the flaps are in the retracted position the right flap, provided with a over-center lock mechanism, acts as a step.

NOTE


The right flap will support a load only in the fully retracted (up) position. When loading and unloading passengers make sure the flaps are in the retracted (up) position.





FUEL SYSTEM SCHEMATIC

Figure 7-11



**FUEL SELECTOR**

Figure 7-13

### 7.15 FUEL SYSTEM

The fuel system incorporates two fuel tanks, one in each wing. Each has a capacity of 38.5 U.S. gallons, giving a total of 77 gallons, of which 72 gallons is usable. The tanks are attached to the leading edges of the wings and are an integral part of the wing structure. The fuel tanks are vented individually through vent tubes which protrude below the bottom of the wings at the rear outboard corner of each tank. The vents should be checked periodically for obstructions which might block the free passage of air.

Normally, fuel is supplied to the engine through an engine-driven fuel pump. An auxiliary electric fuel pump serves as a back-up feature. The electric fuel pump is controlled by a rocker switch on the switch panel above the throttle quadrant. The electric fuel pump should be ON when switching fuel tanks and during takeoffs and landings.

The fuel tank selector (Figure 7-13), which allows the pilot to select the tank supplying fuel to the engine, is located on the left sidewall of the cockpit, below the instrument panel. It has three positions: OFF, LEFT TANK and RIGHT TANK. The arrow on the handle of the selector points to the tank which is supplying fuel to the engine. The valve also incorporates a safety latch which prevents inadvertently selecting the "OFF" position.

Fuel quantity and pressure are indicated on gauges on the instrument panel. There is a separate fuel quantity gauge for each tank.

**SECTION 7  
DESCRIPTION AND OPERATION**

**PIPER AIRCRAFT CORPORATION  
PA-28R-201, CHEROKEE ARROW III**

Each fuel tank has an individual quick drain located at the bottom inboard rear corner (see Figure 8-3). These drains are opened by insertion of the probe in the fuel sampler container into the drain. The fuel strainer incorporates a drain which protrudes from the cowling at the lower left front corner of the firewall. All three drains should be drained before flights and the drained fuel checked for water, sediment and proper fuel.

**CAUTION**

When draining fuel, care should be exercised to ensure that no fire hazard exists before starting the engine.

### 7.17 ELECTRICAL SYSTEM

The electrical system is very simple and functional. All switches are grouped on a switch panel above the power quadrant. On the lower right side of the instrument panel is the circuit breaker panel, with each breaker clearly marked to show what circuit it protects. Also, circuit provisions are made to handle a complete complement of communication and navigational equipment.

6 ✓ Standard electrical accessories include alternator, starter, electric fuel pump, stall warning indicator, ammeter, and annunciator panel.

The annunciator panel includes alternator and low oil pressure indicator lights. When the optional gyro system is installed, the annunciator panel also includes a low vacuum indicator light. The annunciator panel lights are provided only as a warning to the pilot that a system may not be operating properly, and that he should check and monitor the applicable system gauge to determine when or if any necessary action is required.

LIGHTS ✓ Optional electrical accessories include navigation, anti-collision, landing, instrument and cabin dome lights. Navigation and radio lights are controlled by a rheostat switch on the left side of the switch panel. The instrument panel lights are controlled by a rheostat switch on the right side of the panel.

#### WARNING

When optional panel lights are installed, rheostat switch must be off to obtain gear lights full intensity during daytime flying. When aircraft is operated at night and panel light rheostat switch is turned on, gear lights will automatically dim.

The anti-collision and landing lights are controlled by rocker switches on the switch panel. Circuits will handle a full complement of communications and navigational equipment.


#### WARNING

Anti-collision lights should not be operating when flying through cloud, fog or haze, since the reflected light can produce spatial disorientation. Strobe lights should not be used in close proximity to the ground such as during taxiing, takeoff or landing.

The master switch, also located in the switch panel, is a split rocker switch. One side of the switch is the battery side ("BAT") and the other is the alternator side ("ALT"). Henceforth, "master switch," used in this manual, shall mean both "BAT" and "ALT" switches. The "ALT" switch is provided for an emergency and its function is covered under "Alternator Failure" in the Emergency section of the handbook.


The primary electrical power source is a 14-volt, 60 amp alternator, which is protected by a voltage regulator and an overvoltage relay. The alternator provides full electrical power output even at low engine RPM. This provides improved radio and electrical equipment operation and increases battery life by reducing battery load.

Secondary power is provided by a 12-volt, 25 ampere hour battery.



ALTERNATOR AND STARTER SCHEMATIC

Figure 7-15



**CIRCUIT BREAKER PANEL**

Figure 7-17

The ammeter as installed does not show battery discharge; rather it shows the electrical load placed on the system. With all the electrical equipment off, and the master switch on, the ammeter will indicate the charging rate of the battery. As each electrical unit is switched on, the ammeter will indicate the total ampere draw of all the units including the battery. For example, the average continuous load for night flying with radios on is about 30 amperes. The 30 ampere value plus 2 amperes for charging the battery will then show on the ammeter, indicating the alternator is functioning properly.

Solenoids, provided in the battery and starter circuits, are used to control high current drain functions remotely from the cabin.

The master switch is a split switch with the left half operating the master relay and the right half energizing the alternator. This switch is interlocked so that the alternator cannot be operated without the battery. For normal operation, be sure that both halves are turned on.

**WARNING**

When optional panel lights are installed, radio dimming switch must be off to obtain gear lights full intensity during daytime flying. When aircraft is operated at night and panel light radio dimming switch is turned on, gear lights will automatically dim.

### 7.19 VACUUM SYSTEM

The vacuum system is designed to operate the air driven gyro instruments. This includes the directional and attitude gyros when installed. The system consists of an engine driven vacuum pump, a vacuum regulator, a filter and the necessary plumbing.

The vacuum pump is a dry type pump which eliminates the need for an air/oil separator and its plumbing. A shear drive protects the engine from damage. If the drive shears the gyros will become inoperative.

The vacuum gauge, mounted on the right instrument panel to the right of the radios, (refer to Figure 7-21) provides valuable information to the pilot about the operation of the vacuum system. A decrease in pressure in a system that has remained constant over an extended period, may indicate a dirty filter, dirty screens, possibly a sticking vacuum regulator or leak in system (a low vacuum indicator light is provided in the annunciator panel). Zero pressure would indicate a sheared pump drive, defective pump, possibly a defective gauge or collapsed line. In the event of any gauge variation from the norm, the pilot should have a mechanic check the system to prevent possible damage to the system components or eventual failure of the system.

A vacuum regulator is provided in the system to protect the gyros. The valve is set so the normal vacuum reads 4.8 to 5.2 inches of mercury, a setting which provides sufficient vacuum to operate all the gyros at their rated RPM. Higher settings will damage the gyros and with a low setting the gyros will be unreliable. The regulator is located behind the instrument panel.

### 7.21 PITOT-STATIC SYSTEM

The system supplies both pitot and static pressure for the airspeed indicator, altimeter and vertical speed indicator (when installed).

Pitot pressure is picked up by the pitot head on the underside of the left wing. An optional heated pitot head, which alleviates problems with icing or heavy rain, is available. The switch for pitot heat is located on the switch panel.


Static pressure is sensed by static buttons on each side of the aft fuselage. Push-button type pitot and static drains are located on the lower left sidewall of the cockpit.

An alternate static source is available as optional equipment. The control valve is located below the left side of the instrument panel. When the valve is set in the alternate position, the altimeter, vertical speed indicator and airspeed indicator will be using cabin air for static pressure. The storm window and cabin vents must be closed and the cabin heater and defroster must be on during alternate static source operation. The altimeter error is less than 50 feet unless otherwise placarded.

To prevent bugs and water entering the pitot pressure hole when the airplane is parked, a cover should be placed over the pitot head. A partially or completely blocked pitot head will give erratic or zero readings on the instruments.

#### NOTE


During preflight, check to make sure the pitot cover is removed.



PITOT-STATIC SYSTEM

Figure 7-19





INSTRUMENT PANEL


Figure 7-21

### 7.23 INSTRUMENT PANEL

The instrument panel of the Cherokee Arrow III is designed to accommodate the customary advanced flight instruments and the normally required power plant instruments. The artificial horizon and directional gyro are vacuum operated and are located in the center of the left hand instrument panel. The vacuum gauge is located on the right hand instrument panel. The turn indicator, on the left side, is electrically operated.

The radios are located in the center section of the panel, and the circuit breakers are in the lower right corner of the panel.

An annunciator panel is mounted in the upper instrument panel to warn the pilot of a possible malfunction in the alternator, oil pressure, or vacuum systems.



**CABIN DOOR LATCH**

Figure 7-23

### 7.25 CABIN FEATURES

The interior has been designed for passenger comfort and safety. All seat backs have three positions: normal, intermediate and recline. The adjustment lever is located at the base of the seat back on the outboard side of the seat. The front seats adjust fore and aft for ease of entry and occupant comfort. An armrest is located on the side panels adjacent to the front seat. The rear seats are easily removed to provide room for bulky items. Some rear seat installations incorporate leg retainers with latching mechanisms which must be released before the rear seats can be removed. Releasing the retainers is accomplished on early models by turning the latching mechanisms 90° with a coin or screwdriver. Releasing the retainers is accomplished on later models by depressing the plunger behind each rear leg. Optional headrests are available.

A single strap shoulder harness controlled by an inertia reel, located above the side window, protects each front seat occupant. Optional shoulder straps for the rear occupants are available. The shoulder strap is routed over the shoulder adjacent to the window and attached to the lap belt in the general area of the occupant's inboard hip. A check of the inertia reel mechanism can be made by pulling sharply on the strap and checking that the reel will lock in place under sudden stress; this locking feature prevents the strap from extending and holds the occupant in place. Under normal movement the strap will extend and retract as required. Shoulder harnesses should be routinely worn during take-off, landing and whenever an inflight emergency situation occurs.

Additional features include pilot storm window, two sun visors, ashtrays for each occupant, map pockets located on the side panels below the instrument panel, miscellaneous pockets on the rear of the front seat backs, armrests for the front occupants, cabin or baggage door locks and ignition lock.


The cabin door is double latched. To close the cabin door, hold the door closed with the armrest while moving the side door latch to the "LATCHED" position. Then engage the top latch. Both latches must be secured before flight.

#### 7.27 BAGGAGE AREA

The airplane has a 24 cubic foot aft baggage compartment located behind the rear seats and accessible through the cargo door on the aft side of the fuselage or from inside the cabin. Maximum capacity is 200 pounds. Tie down straps are provided and should be used at all times.

#### NOTE

It is the pilot's responsibility to be sure when the baggage is loaded that the airplane's C.G. falls within the allowable C.G. range. (Refer to Weight and Balance Section.)



HEATING, VENTILATING AND DEFROSTING SYSTEM

Figure 7-25

## 7.29 HEATING AND VENTILATING SYSTEM

The heating system is designed to provide maximum comfort for the occupants during winter and cool weather flights. The system includes a heat shroud, heat ducts, defroster outlets, heat and defroster controls.

### CAUTION

When cabin heat is operated, heat duct surface becomes hot. This could result in burns if arms or legs are placed too close to heat duct outlets or surface.

An opening in the front of the lower cowl admits ram air to the heater shroud and then the air is ducted to the heater shut-offs on the right and left side of the firewall. When the shut-offs are opened the heated air then enters the heat ducts located along each side of the center console. Outlets in the heat duct are located at each seat location. Airflow to the rear seats can be regulated by controls in the heat ducts located between the front seats. The temperature of the cabin is regulated by the heater control located on the right side of the instrument panel.

Defrosting is accomplished by heat outlets located on the right and left side of the cowl cover. Heated air is ducted directly to defroster shut-off valves at the firewall, then to the defroster outlets. The airflow is regulated by a defroster control located below the heat control.

To aid air distribution, the cabin air is exhausted overboard by an outlet located on the bottom of the fuselage. Cabin exhaust outlets are located below and outboard of the rear seats. The above features are removed when air conditioning is installed.

Optional individual overhead fresh air outlets supply fresh air from an air inlet located on the tip of the vertical fin. The air is directed to a plenum chamber at the base of the fin, then ducted to the individual outlets. For individual comfort, the amount and direction of air can be regulated to control the amount of air and direction of desired airflow. An optional blower is available which forces outside air through the overhead vents for ground use. The blower is operated by a "FAN" switch with 4 positions - "OFF," "LOW," "MED," or "HIGH."

## 7.31 STALL WARNING

An approaching stall is indicated by a stall warning horn which is activated between five and ten knots above stall speed. Mild airframe buffeting and gentle pitching may also precede the stall. Stall speeds are shown on graphs in the Performance Section. The stall warning horn emits a continuous sound. The landing gear warning horn is different in that it emits a 90 cycle per minute beeping sound. The stall warning horn is activated by a lift detector installed on the leading edge of the left wing. During preflight, the stall warning system should be checked by turning the master switch "ON," lifting the detector and checking to determine if the horn is actuated.

## 7.33 FINISH

All exterior surfaces are primed with etching primer and finished with acrylic lacquer.

### 7.35 AIR CONDITIONING\*

The air conditioning system is a recirculating air system. The major components include an evaporator, a condenser, a compressor, a blower, switches and temperature controls.

The evaporator is located behind the left rear side of the baggage compartment. This cools the air used for the air conditioning system.

The condenser is mounted on a retractable scoop located on the bottom of the fuselage and to the rear of the baggage compartment area. The scoop extends when the air conditioner is ON and retracts to a flush position when the system is OFF.

The compressor is mounted on the forward right underside of the engine. It has an electric clutch which automatically engages or disengages the compressor to the belt drive system of the compressor.

Air from the baggage area is drawn through the evaporator by the blower and distributed through an overhead duct to individual outlets located adjacent to each occupant.

The switches and temperature control are located on the lower right side of the instrument panel in the climate control center panel. The temperature control regulates the temperature of the cabin. Turning the control clockwise increases cooling; counterclockwise decreases cooling.

The fan speed switch and the air conditioning ON-OFF switch are inboard of the temperature control. The fan can be operated independently of the air conditioning; however, the fan must be on for air conditioner operation. Turning either switch off will disengage the compressor clutch and retract the condenser door. Cooling air should be felt within one minute after the air conditioner is turned on.

#### NOTE

If the system is not operating in 5 minutes, turn the system OFF until the fault is corrected.

The fan switch allows operation of the fan with the air conditioner turned OFF to aid in cabin air circulation. "LOW," "MED" or "HIGH" can be selected to direct a flow of air through the air conditioner outlets in the overhead duct. These outlets can be adjusted or turned off individually.

The condenser door light is located to the right of the engine instrument cluster in front of the pilot. The door light illuminates when the door is open and is off when the door is closed.

A circuit breaker on the circuit breaker panel protects the air conditioning electrical system.

Whenever the throttle is in the full forward position, it actuates a micro switch which disengages the compressor and retracts the scoop. This allows maximum power and maximum rate of climb. The fan continues to operate and the air will remain cool for about one minute. When the throttle is retarded approximately 1/4 inch, the clutch will engage, the scoop will extend, and the system will again supply cool, dry air.

\*Optional equipment

### 7.37 PIPER EXTERNAL POWER\*

An optional starting installation known as Piper External Power (PEP) is accessible through a receptacle located on the right side of the fuselage aft of the baggage compartment door. An external battery can be connected to the socket, thus allowing the operator to crank the engine without having to gain access to the airplane's battery.

### 7.39 EMERGENCY LOCATOR TRANSMITTER\*

The Emergency Locator Transmitter (ELT) when installed, is located in the aft portion of the fuselage just below the stabilator leading edge and is accessible through a plate on the right side of the fuselage. This plate is attached with three slotted-head nylon screws for ease of removal; these screws may be readily removed with a variety of common items such as a dime, a key, a knife blade, etc. If there are no tools available in an emergency the screw heads may be broken off by any means. The ELT is an emergency locator transmitter which meets the requirements of FAR 91.52. The unit operates on a self-contained battery.

The battery has a useful life of 10 years. However, to comply with FAA regulations it must be replaced after 5 years of shelf life or service life. The battery should also be replaced if the transmitter has been used in an emergency situation or if accumulated test time exceeds one hour. The replacement date is marked on the transmitter label.

On the unit itself is a three position selector switch placarded "OFF," "ARM" and "ON." The "ARM" position is provided to set the unit to the automatic position so that it will transmit only after impact and will continue to transmit until the battery is drained to depletion or until the switch is manually moved to the "OFF" position. The "ARM" position is selected when the transmitter is installed at the factory and the switch should remain in that position whenever the unit is installed in the airplane. The "ON" position is provided so the unit can be used as a portable transmitter or in the event the automatic feature was not triggered by impact or to periodically test the function of the transmitter.

Select the "OFF" position when changing the battery, when rearming the unit if it has been activated for any reason, or to discontinue transmission.

#### NOTE

If the switch has been placed in the "ON" position for any reason, the "OFF" position has to be selected before selecting "ARM." If "ARM" is selected directly from the "ON" position, the unit will continue to transmit in the "ARM" position.

A pilot's remote switch, located on the left side panel, is provided to allow the transmitter to be controlled from inside the cabin. The pilot's remote switch is placarded "ON, AUTO/ARM and OFF/RESET." The switch is normally left in the "AUTO/ARM" position. To turn the transmitter off, move the switch momentarily to the "OFF/RESET" position. The aircraft master switch must be "ON" to turn the transmitter "OFF." To actuate the transmitter for tests or other reasons, move the switch upward to the "ON" position and leave it in that position as long as transmission is desired.

\*Optional equipment



**SECTION 7  
DESCRIPTION AND OPERATION**

**PIPER AIRCRAFT CORPORATION  
PA-28R-201, CHEROKEE ARROW III**

---

The unit is equipped with a portable antenna to allow the locator to be removed from the airplane in case of an emergency and used as a portable signal transmitter.

The locator should be checked during the ground check to make certain the unit has not been accidentally activated. Check by tuning a radio receiver to 121.5 MHz. If there is an oscillating sound, the locator may have been activated and should be turned off immediately. Reset to the "ARM" position and check again to insure against outside interference.

**NOTE**

If for any reason a test transmission is necessary, the test transmission should be conducted only in the first five minutes of any hour and limited to three audio sweeps. If tests must be made at any other time, the tests should be coordinated with the nearest FAA tower or flight service station.

TABLE OF CONTENTS

SECTION 8

AIRPLANE HANDLING, SERVICING AND MAINTENANCE

Paragraph No.		Page No.
8.1	General . . . . .	8-1
8.3	Airplane Inspection Periods . . . . .	8-3
8.5	Preventive Maintenance . . . . .	8-4
8.7	Airplane Alterations . . . . .	8-5
8.9	Ground Handling . . . . .	8-6
8.11	Engine Air Filter . . . . .	8-8
8.13	Brake Service . . . . .	8-8
8.15	Landing Gear Service . . . . .	8-10
8.17	Propeller Service . . . . .	8-10
8.19	Oil Requirements . . . . .	8-10
8.21	Fuel System . . . . .	8-11
8.23	Tire Inflation . . . . .	8-13
8.25	Battery Service . . . . .	8-13
8.27	Cold Weather Operation . . . . .	8-13
8.29	Cleaning . . . . .	8-14

## SECTION 8

### AIRPLANE HANDLING, SERVICING, AND MAINTENANCE

#### 8.1 GENERAL

This section provides guidelines relating to the handling, servicing, and maintenance of the Cherokee Arrow III. For complete maintenance instructions, refer to the PA-28 Service Manual.

Every owner should stay in close contact with an authorized Piper Service Center or Piper's Customer Services Department to obtain the latest information pertaining to their airplane, and to avail themselves of Piper Aircraft's support systems.

Piper Aircraft Corporation takes a continuing interest in having owners get the most efficient use from their airplane and keeping it in the best mechanical condition. Consequently, Piper Aircraft, from time to time, issues service releases including Service Bulletins, Service Letters, Service Spares Letters, and others relating to the airplane.

Piper Service Bulletins are of special importance and Piper considers compliance mandatory. These are sent directly to the latest FAA-registered owners in the United States (U.S.) and Piper Service Centers worldwide. Depending on the nature of the release, material and labor allowances may apply. This information is provided to all authorized Piper Service Centers.

Service Letters deal with product improvements and servicing techniques pertaining to the airplane. They are sent to Piper Service Centers and, if necessary, to the latest FAA-registered owners in the U.S. Owners should give careful attention to Service Letter information.

Service Spares Letters offer improved parts, kits, and optional equipment which were not available originally, and which may be of interest to the owner.

Piper Aircraft Corporation offers a subscription service for Service Bulletins, Service Letters, and Service Spares Letters. This service is available to interested persons such as owners, pilots, and mechanics at a nominal fee, and may be obtained through an authorized Piper Service Center or Piper's Customer Services Department.

Maintenance manuals, parts catalogs, and revisions to both, are available from Piper Service Centers or Piper's Customer Services Department.

Any correspondence regarding the airplane should include the airplane model and serial number to ensure proper response.

### 8.3 AIRPLANE INSPECTION PERIODS

Piper Aircraft Corporation has developed inspection items and required inspection intervals for the PA-28 (see PA-28 Service and Inspection Manuals). The PA-28 Inspection Manual contains appropriate forms, and all inspection procedures should be complied with by a properly trained, knowledgeable, and qualified mechanic at a Piper Authorized Service Center or a reputable repair shop. Piper Aircraft Corporation cannot accept responsibility for the continued airworthiness of any aircraft not maintained to these standards, and/or not brought into compliance with applicable Service Bulletins issued by Piper Aircraft Corporation, instructions issued by the engine, propeller, or accessory manufacturers, or Airworthiness Directives issued by the FAA.

A programmed Inspection, approved by the Federal Aviation Administration (FAA), is also available to the owner. This involves routine and detailed inspections to allow maximum utilization of the airplane. Maintenance inspection costs are reduced, and the maximum standard of continued airworthiness is maintained. Complete details are available from Piper Aircraft Corporation.

In addition, but in conjunction with the above, the FAA requires periodic inspections on all aircraft to keep the Airworthiness Certificate in effect. The owner is responsible for assuring compliance with these inspection requirements and for maintaining proper documentation in logbooks and/or maintenance records.

A spectrographic analysis of the engine oil is available from several sources. This inspection, if performed properly, provides a good check of the internal condition of the engine. To be accurate, induction air filters must be cleaned or changed regularly, and oil samples must be taken and sent in at regular intervals.

### **8.5 PREVENTIVE MAINTENANCE**

The holder of a Pilot Certificate issued under FAR Part 61 may perform certain preventive maintenance described in FAR Part 43. This maintenance may be performed only on an aircraft which the pilot owns or operates and which is not used to carry persons or property for hire, except as provided by applicable FAR's. Although such maintenance is allowed by law, each individual should make a self analysis as to whether he has the ability to perform the work.

All other maintenance required on the airplane should be accomplished by appropriately licensed personnel.

If the above work is accomplished, an entry must be made in the appropriate logbook. The entry should contain:

- (a) The date the work was accomplished.
- (b) Description of the work.
- (c) Number of hours on the aircraft.
- (d) The certificate number of pilot performing the work.
- (e) Signature of the individual doing the work.

### 8.7 AIRPLANE ALTERATIONS

If the owner desires to have his aircraft modified, he must obtain FAA approval for the alteration. Major alterations accomplished in accordance with Advisory Circular 43.13-2, when performed by an A & P mechanic, may be approved by the local FAA office. Major alterations to the basic airframe or systems not covered by AC 43.13-2 require a Supplemental Type Certificate.

The owner or pilot is required to ascertain that the following Aircraft Papers are in order and in the aircraft.

- (a) To be displayed in the aircraft at all times:
  - (1) Aircraft Airworthiness Certificate Form FAA-8100-2.
  - (2) Aircraft Registration Certificate Form FAA-8050-3.
  - (3) Aircraft Radio Station License if transmitters are installed.
  
- (b) To be carried in the aircraft at all times:
  - (1) Pilot's Operating Handbook.
  - (2) Weight and Balance data plus a copy of the latest Repair and Alteration Form FAA-337, if applicable.
  - (3) Aircraft equipment list.

Although the aircraft and engine logbooks are not required to be in the aircraft, they should be made available upon request. Logbooks should be complete and up to date. Good records will reduce maintenance cost by giving the mechanic information about what has or has not been accomplished.

## 8.9 GROUND HANDLING

### (a) Towing

The airplane may be moved on the ground by the use of the nose wheel steering bar that is stowed in the rear baggage compartment or by power equipment that will not damage or excessively strain the nose gear steering assembly. Towing lugs are incorporated as part of the nose gear fork.

#### CAUTION

When towing with power equipment, do not turn the nose gear beyond its steering radius in either direction, as this will result in damage to the nose gear and steering mechanism.

#### CAUTION

Do not tow the airplane when the controls are secured.

In the event towing lines are necessary, ropes should be attached to both main gear struts as high up on the tubes as possible. Lines should be long enough to clear the nose and/or tail by not less than fifteen feet, and a qualified person should ride in the pilot's seat to maintain control by use of the brakes.

### (b) Taxiing

Before attempting to taxi the airplane, ground personnel should be instructed and approved by a qualified person authorized by the owner. Engine starting and shut-down procedures as well as taxi techniques should be covered. When it is ascertained that the propeller back blast, the taxi areas are clear and the parking brake has been released, power should be applied to start the taxi roll, and the following checks should be performed:

- (1) Taxi a few feet forward and apply the brakes to determine their effectiveness.
- (2) Taxi with the propeller set in low pitch, high RPM setting.
- (3) While taxiing, make slight turns to ascertain the effectiveness of the steering.
- (4) Observe wing clearance when taxiing near buildings or other stationary objects. If possible, station an observer outside the airplane.
- (5) When taxiing over uneven ground, avoid holes and ruts.
- (6) Do not operate the engine at high RPM when running up or taxiing over ground containing loose stones, gravel, or any loose material that may cause damage to the propeller blades.

(c) Parking

When parking the airplane, be sure that it is sufficiently protected from adverse weather conditions and that it presents no danger to other aircraft. When parking the airplane for any length of time or overnight, it is suggested that it be moored securely.

- (1) To park the airplane, head it into the wind if possible.
- (2) Set the parking brake by pulling back on the brake lever and depressing the knob on the handle. To release the parking brake, pull back on the handle until the catch disengages; then allow the handle to swing forward.

CAUTION

Care should be taken when setting brakes that are overheated or during cold weather when accumulated moisture may freeze a brake.

- (3) Aileron and stabilator controls should be secured with the front seat belt and chocks used to properly block the wheels.

(d) Mooring

The airplane should be moored for immovability, security and protection. The following procedures should be used for the proper mooring of the airplane:

- (1) Head the airplane into the wind if possible.
- (2) Retract the flaps.
- (3) Immobilize the ailerons and stabilator by looping the seat belt through the control wheel and pulling it snug.
- (4) Block the wheels.
- (5) Secure tie-down ropes to the wing tie-down rings and to the tail skid at approximately 45 degree angles to the ground. When using rope of non-synthetic material, leave sufficient slack to avoid damage to the airplane should the ropes contract.

CAUTION

Use bowline knots, square knots or locked slip knots. Do not use plain slip knots.

NOTE

Additional preparations for high winds include using tie-down ropes from the landing gear forks and securing the rudder.

- (6) Install a pitot head cover if available. Be sure to remove the pitot head cover before flight.
- (7) Cabin and baggage doors should be locked when the airplane is unattended.



### **8.11 ENGINE AIR FILTER**

(a) Removing Engine Air Filter

- (1) Remove top cowl.
- (2) Remove the wing nuts securing the filter. Remove the filter.

(b) Cleaning Engine Air Filter

The induction air filter must be cleaned at least once every 50 hours, and more often, even daily, when operating in dusty conditions. Extra filters are inexpensive, and a spare should be kept on hand for use as a rapid replacement.

To clean the filter:

- (1) Tap the filter gently to remove dirt particles, being careful not to damage the filter. DO NOT wash the filter in any liquid. DO NOT attempt to blow out dirt with compressed air.
- (2) If the filter is excessively dirty or shows any damage, replace it immediately.
- (3) Wipe the filter housing with a clean cloth soaked in unleaded gasoline. When the housing is clean and dry, install the filter.


(c) Installation Of Engine Air Filter

After cleaning or when replacing the filter, install the filter in the reverse order of removal.

### **8.13 BRAKE SERVICE**

The brake system is filled with MIL-H-5606 (petroleum base) hydraulic brake fluid. The fluid level should be checked periodically or at every 100 hour inspection and replenished when necessary. The brake reservoir is located on the left side of the fire wall in the engine compartment. If the entire system must be refilled, fill with fluid under pressure from the brake end of the system. This will eliminate air from the system.

No adjustment of the brake clearances is necessary. If after extended service brake blocks become excessively worn, they should be replaced with new segments.



- 8. LINE, INLET
- 9. CLEVIS PIN
- 10. MASTER CYLINDER ASSEMBLY
- 11. BOLT ASSEMBLY
- 12. TORQUE TUBE
- 13. COPILOT'S RIGHT BRAKE AND RUDDER PEDAL
- 14. COPILOT'S LEFT BRAKE AND RUDDER PEDAL

- 1. BRAKE RESERVOIR
- 2. RIGHT BRAKE AND RUDDER PEDAL
- 3. LEFT BRAKE AND RUDDER PEDAL
- 4. RIGHT BRAKE CYLINDER
- 5. LEFT BRAKE CYLINDER
- 6. BRAKE HANDLE
- 7. HANDLE LOCKING BUTTON

**BRAKE SYSTEM**

Figure 8-1

### 8.15 LANDING GEAR SERVICE

The main landing gear uses 6.00 x 6, six-ply rating tires and tubes. The nose wheel uses a 5.00 x 5 wheel with a 5.00 x 5 four-ply rating, type III tire and tube. (Refer to paragraph 8.23.)

Wheels are removed by taking off the hub cap, cotter pin, axle nut, and the two bolts holding the brake segment in place. Mark tire and wheel for reinstallation; then dismount by deflating the tire, removing the three through-bolts from the wheel and separating the wheel halves.

Landing gear oleos on the Cherokee Arrow III should be serviced according to the instructions on the units. The main oleos should be extended under normal static load until  $2.5 \pm 0.25$  inches of oleo piston tube is exposed, and the nose gear should show  $2.75 \pm 0.25$  inches. To add air to the oleo struts, attach a strut pump to the valve assembly near the top of the oleo strut housing and pump the oleo to the desired position. To add oil, jack the aircraft, release the air pressure in the strut, remove the valve core and add oil through this opening with the strut extended. After the strut is full, compress it slowly and fully to allow excess air and oil to escape. With the strut still compressed reinsert the valve stem and pump up the strut as above.

In jacking the aircraft for landing gear or other service, two hydraulic jacks and a tail stand should be used. At least 250 pounds of ballast should be placed on the base of the tail stand before the airplane is jacked up. The hydraulic jacks should be placed under the jack points on the bottom of the wing and the airplane jacked up until the tail skid is at the right height to attach the tail stand. After the tail stand is attached and the ballast added, jacking may be continued until the airplane is at the height desired.

The steering arms from the rudder pedals to the nose wheel are adjusted at the rudder pedals or at the nose wheel by turning the threaded rod end bearings in or out. Adjustment is normally accomplished at the aft axis of the plane when the rudder pedals and rudder are centered. Alignment of the nose wheel can be checked by pushing the airplane back and forth with the rudder centered to determine that the plane follows a perfectly straight line. The turning arc of the nose wheel is  $30^\circ \pm 2^\circ$  in either direction and is factory adjusted at stops on the bottom of the forging. The steering arm stops should be carefully adjusted so that the nose wheel reaches its full travel just after the rudder hits its stops. This guarantees that the rudder will be allowed to move through its full travel.

### 8.17 PROPELLER SERVICE

The spinner and backing plate should be cleaned and inspected for cracks frequently. Before each flight the propeller should be inspected for nicks, scratches, and corrosion. If found, they should be repaired as soon as possible by a rated mechanic, since a nick or scratch causes an area of increased stress which can lead to serious cracks or the loss of a propeller tip. The back face of the blades should be painted when necessary with flat black paint to retard glare. To prevent corrosion, the surface should be cleaned and waxed periodically.

### 8.19 OIL REQUIREMENTS

The oil capacity of the Lycoming IO-360 series engine is 8 quarts, and the minimum safe quantity is 2 quarts. It is recommended that engine oil be drained and renewed every 50 hours. The oil filter element should be changed every 50 hours of operation. The interval between oil and oil filter changes should not exceed a total of four (4) months. Under unfavorable dusty conditions, the oil and oil filter should be changed more frequently.

The following seasonal aviation oil grades and seasonal ambient temperature ranges are recommended.

Average Ambient Temperature	MIL-L-6082B SAE Grade	MIL-L-22851 Ashless Dispersant SAE Grades
All Temperatures	--	15W-50 or 20W-50
Above 80°F	60	60
Above 60°F	50	40 or 50
30°F to 90°F	40	40
0°F to 70°F	30	30, 40 or 20W-40
Below 10°F	20	30 or 20W-30

When operating temperatures overlap indicated ranges, use the lighter grade oil.

NOTE

Refer to the latest issue of Textron Lycoming Service Instruction 1014 (Lubricating Oil Recommendations) for further information.

8.21 FUEL SYSTEM

(a) Servicing Fuel System

At every 50 hour inspection, the fuel screens in the strainer and in the injector must be cleaned. The screen in the injector is located in the housing where the fuel line connects to the injector. The fuel strainer is located under the floor panel and is accessible for cleaning through an access plate on the underside of the fuselage. After cleaning, a small amount of grease applied to the gasket will facilitate reassembly.

(b) Fuel Requirements (AVGAS ONLY)

The minimum aviation grade fuel is 100. Since the use of lower grades can cause serious engine damage in a short period of time, the engine warranty is invalidated by the use of lower octanes.

Whenever 100 or 100LL grade fuel is not available, commercial grade 100/130 should be used. Refer to the latest issue of Lycoming Service Instruction No. 1070 for additional information.


A summary of the current grades as well as the previous fuel designations is shown in the following chart:

FUEL GRADE COMPARISON CHART

Previous Commercial Fuel Grades (ASTM-D910)			Current Commercial Fuel Grades (ASTM-D910-75)			Current Military Fuel Grades (MIL-G-5572E) Amendment No. 3		
Grade	Color	Max. TEL ml/U.S. gal.		Color	Max. TEL ml/U.S. gal.		Color	Max. TEL ml/U.S. gal.
80/87	red	0.5	80	red	0.5	80/87	red	0.5
91/98	blue	2.0	*100LL	blue	2.0	none	none	none
100/130	green	3.0	100	green	**3.0	100/130	green	**3.0
115/145	purple	4.6				115/145	purple	4.6

\* - Grade 100LL fuel in some over seas countries is currently colored green and designated as 100L.

\*\* - Commercial fuel grade 100 and grade 100/130 (both of which are colored green) having TEL content of up to 4 ml/U.S. gallon are approved for use in all engines certificated for use with grade 100/130 fuel.



**FUEL DRAIN**  
Figure 8-3

(c) Filling Fuel Tanks

Observe all safety precautions required when handling gasoline. Fill the fuel tanks through the filler located on the forward slope of the wing. Each wing holds a maximum of 38.5 U.S. gallons. When using less than the standard 77 gallon capacity, fuel should be distributed equally between each side.

(d) Draining Fuel Valves and Lines

The fuel strainer, located on the lower left side of the firewall, is provided with a quick drain which should be drained before the first flight of the day or after refueling, to check for proper fuel and fuel contamination (such as water, sediment, etc.). If contamination is found, fuel should be drained until the contamination stops. If contamination persists after draining fuel for a minute or improper fuel is observed, contact a mechanic to check the fuel system.

Each fuel tank is provided with a fuel quick drain. Each tank should be checked in accordance with the above procedure.

(e) Draining Fuel System

The bulk of the fuel may be drained from the fuel cells by the use of a siphon hose placed in the cell or tank through the filler-neck. The remainder of the fuel may be drained by opening all the drain valves.

### CAUTION

When draining fuel, be sure that no fire hazard exists before starting the engine.

### 8.23 TIRE INFLATION

For maximum service from the tires, keep them inflated to the proper pressure of 27 psi for nose tire and 30 psi for main tires. Interchange the tires periodically for even wear. All wheels and tires are balanced before original installation, and the relationship of tire, tube and wheel should be maintained upon reinstallation. In the installation of new components, it may be necessary to rebalance the wheels with the tires mounted. Unbalanced wheels can cause extreme vibration in the landing gear.

### 8.25 BATTERY SERVICE

Access to the 12-volt 25-ampere-hour battery is gained through the baggage compartment. It is located just aft of the baggage compartment. The battery container has a plastic drain tube which is normally closed off. This tube should be drained periodically to remove battery acid which may have collected in the tube.

The battery fluid level must not be brought above the baffle plates. It should be checked every 30 days to determine that the fluid level is proper and the connections are tight and free of corrosion.

If the battery is not properly charged, recharge it starting with a rate of four amperes and finishing with a rate of two amperes. The battery should be removed from the airplane for charging, and quick charges are not recommended.

The external power receptacle, if installed, is located on the right side of the fuselage aft of the baggage compartment door.

Refer to the Cherokee Arrow III Service Manual for battery servicing procedure.

### 8.27 COLD WEATHER OPERATION

For cold weather operation a winterization kit is installed on the inlet opening of the oil cooler plenum chamber. This kit should be installed whenever the ambient temperature is 50° F or less. When the kit is not being used, it can be stowed on a bracket provided for this purpose on the top side of the oil cooler plenum chamber.

It is recommended that an optional Engine Breather Tube Winterization Kit be installed for cold weather operation. This kit is available through your Piper Dealer Distributor.

## 8.29 CLEANING

### (a) Cleaning Engine Compartment

Before cleaning the engine compartment, place a strip of tape on the magneto vents to prevent any solvent from entering these units.

- (1) Place a large pan under the engine to catch waste.
- (2) With the engine cowling removed, spray or brush the engine with solvent or a mixture of solvent and degreaser. In order to remove especially heavy dirt and grease deposits, it may be necessary to brush areas that were sprayed.

#### CAUTION

Do not spray solvent into the alternator, vacuum pump, starter, or air intakes.

- (3) Allow the solvent to remain on the engine from five to ten minutes. Then rinse the engine clean with additional solvent and allow it to dry.

#### CAUTION

Do not operate the engine until excess solvent has evaporated or otherwise been removed.

- (4) Remove the protective tape from the magnetos.
- (5) Lubricate the controls, bearing surfaces, etc., in accordance with the Lubrication Chart.

### (b) Cleaning Landing Gear

Before cleaning the landing gear, place a plastic cover or similar material over the wheel and brake assembly.

- (1) Place a pan under the gear to catch waste.
- (2) Spray or brush the gear area with solvent or a mixture of solvent and degreaser, as desired. Where heavy grease and dirt deposits have collected, it may be necessary to brush areas that were sprayed, in order to clean them.
- (3) Allow the solvent to remain on the gear from five to ten minutes. Then rinse the gear with additional solvent and allow to dry.
- (4) Remove the cover from the wheel and remove the catch pan.
- (5) Lubricate the gear in accordance with the Lubrication Chart.
- (6) Caution: Do not brush the micro switches.

(c) Cleaning Exterior Surfaces

The airplane should be washed with a mild soap and water. Harsh abrasives or alkaline soaps or detergents could make scratches on painted or plastic surfaces or could cause corrosion of metal. Cover areas where cleaning solution could cause damage. To wash the airplane, use the following procedure:

- (1) Flush away loose dirt with water.
- (2) Apply cleaning solution with a soft cloth, a sponge or a soft bristle brush.
- (3) To remove exhaust stains, allow the solution to remain on the surface longer.
- (4) To remove stubborn oil and grease, use a cloth dampened with naphtha.
- (5) Rinse all surfaces thoroughly.
- (6) Any good automotive wax may be used to preserve painted surfaces. Soft cleaning cloths or a chamois should be used to prevent scratches when cleaning or polishing. A heavier coating of wax on the leading surfaces will reduce the abrasion problems in these areas.

(d) Cleaning Windshield and Windows

- (1) Remove dirt, mud and loose particles from exterior surfaces with clean water.
- (2) Wash with mild soap and warm water or with aircraft plastic cleaner. Use a soft cloth or sponge in a straight back and forth motion. Do not rub harshly.
- (3) Remove oil and grease with a cloth moistened with kerosene.

CAUTION

Do not use gasoline, alcohol, benzene, carbon tetrachloride, thinner, acetone, or window cleaning sprays.

- (4) After cleaning plastic surfaces, apply a thin coat of hard polishing wax. Rub lightly with a soft cloth. Do not use a circular motion.
- (5) A severe scratch or mar in plastic can be removed by rubbing out the scratch with jeweler's rouge. Smooth both sides and apply wax.

(e) Cleaning Headliner, Side Panels and Seats

- (1) Clean headliner, side panels, and seats with a stiff bristle brush, and vacuum where necessary.
- (2) Soiled upholstery, except leather, may be cleaned with a good upholstery cleaner suitable for the material. Carefully follow the manufacturer's instructions. Avoid soaking or harsh rubbing.

CAUTION

Solvent cleaners require adequate ventilation.

- (3) Leather should be cleaned with saddle soap or a mild hand soap and water.

(f) Cleaning Carpets

To clean carpets, first remove loose dirt with a whisk broom or vacuum. For soiled spots and stubborn stains use a nonflammable dry cleaning fluid. Floor carpets may be cleaned like any household carpet.



TABLE OF CONTENTS

SECTION 9

SUPPLEMENTS

Paragraph/Supplement No.		Page No.
9.1	General . . . . .	9-1
1	Air Conditioning System Installation . . . . .	9-3
2	AutoFlite II Autopilot Installation . . . . .	9-7
3	AutoControl IIIB Autopilot Installation . . . . .	9-9
4	Piper Electric Pitch Trim . . . . .	9-13

SECTION 9  
SUPPLEMENTS

9.1 GENERAL

This section provides information in the form of Supplements which are necessary for efficient operation of the airplane when equipped with one or more of the various optional systems and equipment not provided with the standard airplane.

All of the Supplements provided by this section are "FAA Approved" and consecutively numbered as a permanent part of this Handbook. The information contained in each Supplement applies only when the related equipment is installed in the airplane.

SUPPLEMENT 1

AIR CONDITIONING INSTALLATION

SECTION 1 - GENERAL

This supplement supplies information necessary for the efficient operation of the airplane when the optional air conditioning system is installed. The information contained within this supplement is to be **used in conjunction with the complete handbook.**

This supplement has been "FAA Approved" as a permanent part of this handbook and must remain in this handbook at all times when the optional air conditioning system is installed.

SECTION 2 - LIMITATIONS

- (a) To insure maximum climb performance the air conditioner must be turned "OFF" manually prior to takeoff to disengage the compressor and retract the condenser door. Also the air conditioner must be turned "OFF" manually before the landing approach in preparation for a possible go-around.

- (b) Placards

In full view of the pilot, in the area of the air conditioner controls when the air conditioner is installed:

"WARNING - AIR CONDITIONER MUST BE OFF TO INSURE  
NORMAL TAKEOFF CLIMB PERFORMANCE."

In full view of the pilot, to the right of the engine gauges (condenser door light):

"AIR COND DOOR  
OPEN"

SECTION 3 - EMERGENCY PROCEDURES

No changes to the basic Emergency Procedures provided by Section 3 of this Pilot's Operating Handbook are necessary for this supplement.

#### SECTION 4 - NORMAL PROCEDURES

Prior to takeoff the air conditioner should be checked for proper operation as follows:

- (a) Check aircraft master switch "ON."
- (b) Turn the air conditioner control switch to "ON" and the fan switch to one of the operating positions - the "AIR COND DOOR OPEN" warning light will turn on, thereby indicating proper air conditioner condenser door actuation.
- (c) Turn the air conditioner control switch to "OFF" - the "AIR COND DOOR OPEN" warning light will go out, thereby indicating the air conditioner condenser door is in the up position.
- (d) If the "AIR COND DOOR OPEN" light does not respond as specified above, an air conditioner system or indicator bulb malfunction is indicated and further investigation should be conducted prior to flight.

The above operational check may be performed during flight if an in flight failure is suspected.

The condenser door light is located to the right of the engine instrument cluster in front of the pilot. The door light illuminates when the door is open and is off when the door is closed.

#### SECTION 5 - PERFORMANCE

Operation of the air conditioner will cause slight decreases in cruise speed and range. Power from the engine is required to run the compressor, and the condenser door, when extended, causes a slight increase in drag. When the air conditioner is turned off there is normally no measurable difference in cruise or range performance of the airplane.

#### NOTE

To insure maximum climb performance the air conditioner must be turned off manually before takeoff to disengage the compressor and retract the condenser door. Also the air conditioner must be turned off manually before the landing approach in preparation for a possible go-around.

Although the cruise speed and range are only slightly affected by the air conditioner operation, these changes should be considered in preflight planning. To be conservative, the following figures assume that the compressor is operating continuously while the airplane is airborne. This will be the case only in extremely hot weather.

- (a) The decrease in true airspeed is approximately 6 KTS at all power settings.
- (b) The decrease in range may be as much as 40 nautical miles for the 72 gallon usable fuel capacity.

The climb performance is not compromised measurably with the air conditioner operating since the compressor is declutched and the condenser door is retracted, both automatically, when a full throttle position is selected. When the full throttle position is not used or in the event of a malfunction which would cause the compressor to operate and the condenser door to be extended, a decrease in rate of climb of as much as 100 fpm can be expected. Should a malfunction occur which prevents condenser door retraction when the compressor is turned off, a decrease in rate of climb of as much as 50 fpm can be expected.

SUPPLEMENT 2

AUTOFLITE II AUTOPILOT INSTALLATION

SECTION 1 - GENERAL

This supplement supplies information necessary for the operation of the airplane when the optional AutoFlite II Autopilot is installed. The information contained within this supplement is to be used in conjunction with the complete handbook.

This supplement has been "FAA Approved" as a permanent part of this handbook based on EDO-AIRE Mitchell STC SA3162SW-D and must remain in this handbook at all times when the optional AutoFlite II Autopilot is installed.

SECTION 2 - LIMITATIONS

- (a) Autopilot operation prohibited above 175 KIAS. (Autopilot V<sub>mo</sub>)
- (b) Autopilot must be "OFF" for takeoff and landing.

SECTION 3 - EMERGENCY PROCEDURES

- (a) In case of malfunction, depress disconnect switch on pilot's control wheel, or overpower autopilot at either control wheel.
- (b) AutoFlite II master switch - OFF.
- (c) In climb, cruise or descent configuration a malfunction with a 3 second delay in recovery initiation may result in 50° bank and 190 foot altitude loss. Maximum altitude loss measured at 175 KIAS in a descent.
- (d) In approach configuration, coupled or uncoupled, a malfunction with a 1 second delay in recovery initiation may result in 18° bank and 20 foot altitude loss.

SECTION 4 - NORMAL PROCEDURES

AUTOFLITE II PREFLIGHT INSPECTION

- (a) AutoFlite II master switch - ON.
- (b) Rotate turn command knob to left and right. Aircraft control wheels should rotate in corresponding directions.
- (c) With AutoFlite II on, rotate aircraft control wheel to left and right. Only light forces should be required to override roll servo clutch.
- (d) AutoFlite II master switch - OFF - rotate control wheel left and right to assure disengagement.

### AUTOFLITE II IN-FLIGHT PROCEDURE

- (a) Engagement
  - (1) Check turn command knob in center detent position.
  - (2) AutoFlite II master switch - ON.
- (b) Disengagement
  - (1) AutoFlite II master switch - OFF.
- (c) Heading Changes
  - (1) Move trim knob on instrument for drift correction from a constant heading.
  - (2) Move turn command knob for left or right banked turns. Rotation of knob to stop will yield an appropriate bank angle to obtain an approximate standard rate turn. Intermediate settings may be used for lesser turn rates.
- (d) OMNI Tracker
  - (1) Turn command knob - move to center detent position and push IN to engage tracker. Aircraft will track desired radial established on NAV 1 (or as selected, if equipped with a NAV selector switch).

#### NOTE

Tracker must be engaged within 10° of being "on course," i.e. VOR course needle centered and aircraft heading within 10° of VOR course.

- (2) Trim knob - push IN for high sensitivity. Use high sensitivity position for localizer tracking and as desired for OMNI tracking.
- (e) Maintain directional trim during all autopilot operations.

### PERFORMANCE

No changes to the basic performance provided by Section 5 of this Pilot's Operating Handbook are necessary for this supplement.

SUPPLEMENT 3

AUTOCONTROL IIIB AUTOPILOT INSTALLATION

SECTION 1 - GENERAL

This supplement supplies information necessary for the operation of the airplane when the optional Piper AutoControl IIIB Autopilot is installed. The information contained within this supplement is to be used in conjunction with the complete handbook.

This supplement has been FAA Approved as a permanent part of this handbook based on EDO=AIRE Mitchell STC SA3161SW-D and must remain in this handbook at all times when the optional Piper AutoControl IIIB Autopilot is installed.

SECTION 2 - LIMITATIONS

- (a) Autopilot operation prohibited above 175 KIAS. (Autopilot  $V_{MO}$ )
- (b) Autopilot must be OFF for takeoff and landing.

SECTION 3 - EMERGENCY PROCEDURES

- (a) In an emergency the AutoControl IIIB can be disconnected by:
  - (1) Pushing the A/P ON-OFF rocker switch - OFF.
- (b) The autopilot can be overpowered at either control wheel.
- (c) An autopilot runaway, with a 3 second delay in the initiation of recovery while operating in climb, cruise or descending flight, could result in a 58° bank and 190 foot altitude loss.  
Maximum altitude loss measured at 175 KIAS in a descent.
- (d) An autopilot runaway, with a 1 second delay in the initiation of recovery, during an approach operation, coupled or uncoupled, could result in an 18° bank and 20 foot altitude loss.
- (e) Emergency operation with optional NSD 360 and NSD 360A (HSI) - Slaved and/or Non-Slaved:

NSD 360

- (1) Appearance of HDG Flag:
  - a. Check air supply gauge (vac or pressure) for adequate air supply (4 in. Hg. min.).
  - b. Check compass circuit breaker.
  - c. Observe display for proper operation.
- (2) To disable heading card - pull circuit breaker and use magnetic compass for directional data.

NOTE

If heading card is not operational, autopilot should not be used.



- (3) With card disabled:
  - a. VOR and Glide Slope displays are still functional; use card set to rotate card to aircraft heading for correct picture.
  - b. Localizer - left-right information still usable. Flag information is disabled - compare needle with No. 2 indicator for valid left-right needle operation.
- (4) Slaving Failure - (i.e. failure to self-correct for gyro drift):
  - a. Check gyro slaving switch is set to No. 1 position.
  - b. Check for HDG Flag.
  - c. Check compass circuit breaker.
  - d. Reset heading card while observing slaving meter.
  - e. Select slaving amplifier No. 2 (gyro slaving switch is set to No. 2 position).
  - f. Reset heading card while checking slaving meter.
  - g. Switch to free gyro and periodically set card as unslaved gyro.

NSD 360A (Instrument with red-white striped NAV-HDG Flags)

- (1) The emergency procedures for the NSD 360A remain identical to those listed for the NSD 360 (above), except that the presence of the NAV Flag on a localizer frequency invalidates the NAV left-right information. Usable navigation data will be indicated in both VOR and Localizer modes by the absence of the NAV Flag, whether the card is disabled or not.
- (2) In the localizer mode the "TO-FROM" arrows may remain out of view, depending upon the design of the NAV converter used in the installation.

SECTION 4 - NORMAL PROCEDURES

PREFLIGHT

- (a) AUTOPILOT
  - (1) Place radio coupler in HDG mode (if installed) and place the A/P "ON-OFF" switch to the "ON" position to engage roll section. Rotate roll command knob left and right and observe that control wheel describes a corresponding left and right turn, then center knob.
  - (2) Set proper D.G. heading on D.G. and turn HDG bug to aircraft heading. Engage HDG mode rocker switch and rotate HDG bug right and left. Aircraft control wheel should turn same direction as bug. Grasp control wheel and manually override servo, both directions.
- (b) RADIO COUPLER - (OPTIONAL)
  - (1) Tune and identify VOR or VOT station. Position radio coupler to OMNI mode. Engage autopilot "ON" and HDG switches. Set HDG bug to aircraft heading and rotate OBS to cause OMNI indicator needle to swing left and right slowly. Observe that control wheel rotates in direction of needle movement.
  - (2) Disengage A/P "ON-OFF" switch. Reset radio coupler control to HDG.

IN-FLIGHT

- (a) Trim airplane (ball centered).
- (b) Check air pressure or vacuum to ascertain that the directional gyro and attitude gyro are receiving sufficient air.

- (c) Roll Section:
- (1) To engage, center roll knob, push A/P "ON-OFF" switch to "ON" position. To turn, rotate console roll knob in desired direction. (Maximum angle of bank should not exceed 30°.)
  - (2) For heading mode, set directional gyro with magnetic compass. Push directional gyro HDG knob in, rotate bug to aircraft heading. Push console heading rocker (HDG) switch to "ON" position. To select a new aircraft heading, push D.G. heading knob "IN" and rotate, in desired direction of turn, to the desired heading.
- (d) Radio Coupling VOR-ILS with H.S.I. (Horizontal Situation Indicator) Type Instrument Display - (Optional)
- (1) VOR Navigation
    - a. Tune and identify VOR station. Select desired course by rotating CRS knob of H.S.I.
    - b. Select OMNI mode on radio coupler.
    - c. Select HDG mode on autopilot console to engage coupler. Aircraft will turn to a 45° intercept angle to intercept the selected VOR course. Intercept angle magnitude depends on radio needle off course magnitude, 100% needle deflection will result in 45° intercept with the intercept angle diminishing as the needle offset diminishes.
    - d. NAV mode - NAV mode provides reduced VOR sensitivity for tracking weak, or noisy VOR signals. NAV mode should be selected after the aircraft is established on course.
  - (2) ILS-LOC Front Course
    - a. Set inbound, front, localizer course on H.S.I.
    - b. Select LOC-Normal on radio coupler to intercept and track inbound on localizer. Select LOC-REV to intercept and track outbound to the procedure turn area.
    - c. Select HDG mode on autopilot console to engage coupler.
  - (3) ILS - Back Course
    - a. Set inbound, front localizer course on H.S.I.
    - b. Select LOC-REV on radio coupler to intercept and track inbound on the back localizer course. Select LOC-NORM to intercept and track outbound on the back course to the procedure turn area.
    - c. Select HDG mode on autopilot console to engage coupler.
- (e) Radio Coupling - VOR-ILS with standard directional gyro. (Optional)
- Radio coupler operation in conjunction with a standard directional gyro and VOR-LOC display differs from operation with an integrated display (H.S.I.) only in one respect. The HDG bug is used as the radio course datum and therefore must be set to match the desired VOR course as selected on the OBS.
- (1) For VOR intercepts and tracking:

Select the desired VOR course and set the HDG bug to the same heading. Select OMNI mode on the coupler and HDG mode on the autopilot console.
  - (2) For ILS Front Course intercepts and tracking:

Tune the localizer frequency and place the HDG bug on the inbound, front course heading. Select LOC-NORM mode on the coupler and HDG mode on the autopilot console.
  - (3) For LOC Back Course intercepts and tracking:

Tune the localizer frequency and place the HDG bug on the inbound course heading to the airport. Select LOC-REV mode with coupler and HDG mode on the autopilot console.

**SECTION 5 - PERFORMANCE**

No changes to the basic performance provided by Section 5 of the Pilot's Operating Handbook are necessary for this supplement.

SUPPLEMENT 4

PIPER ELECTRIC PITCH TRIM

SECTION 1 - GENERAL

This supplement supplies information necessary for the operation of the airplane when the optional Piper Electric Pitch Trim is installed. The information contained within this supplement is to be used in conjunction with the complete handbook.

This supplement has been "FAA Approved" as a permanent part of this handbook and must remain in this handbook at all times when the optional Piper Electric Pitch Trim is installed.

SECTION 2 - LIMITATIONS

No changes of the basic limitations provided by Section 2 of this Pilot's Operating Handbook are necessary for this supplement.

SECTION 3 - EMERGENCY PROCEDURES

- (a) In case of malfunction, PRESS disconnect switch located above the ignition switch.
- (b) In case of malfunction, overpower the electric trim at either control wheel.
- (c) Maximum altitude change with a 4 second delay in recovery initiation is 500 feet and occurs in the power approach and cruise configurations, and results in a 20° pitch change.

SECTION 4 - NORMAL PROCEDURES

The electric trim system may be turned ON or OFF by a switch located above the ignition switch. The pitch trim may be changed when the electric trim system is turned on either by moving the manual pitch trim control wheel or by operating the trim control switch on the pilot's control yoke.

SECTION 5 - PERFORMANCE

No changes to the basic performance provided by Section 5 of this Pilot's Operating Handbook are necessary for this supplement.

TABLE OF CONTENTS

SECTION 10

OPERATING TIPS

Paragraph No.		Page No.
10.1	General .....	10-1
10.3	Operating Tips .....	10-1

SECTION 10  
OPERATING TIPS

10.1 GENERAL

This section provides operating tips of particular value in the operation of the Cherokee Arrow III.

10.3 OPERATING TIPS

- (a) Learn to trim for takeoff so that only a very light back pressure on the control wheel is required to lift the airplane off the ground.
- (b) The best speed for takeoff is about 70 KIAS under normal conditions. Trying to pull the airplane off the ground at too low an airspeed decreases the controllability of the airplane in the event of engine failure.
- (c) Flaps may be lowered at airspeeds up to 103 KIAS. To reduce flap operating loads, it is desirable to have the airplane at a slower speed before extending the flaps. The flap step will not support weight if the flaps are in any extended position. The flaps must be placed in the "UP" position before they will lock and support weight on the step.
- (d) Before attempting to reset any circuit breaker, allow a two to five minute cooling off period.
- (e) Before starting the engine, check that all radio switches, light switches and the pitot heat switch are in the off position so as not to create an overloaded condition when the starter is engaged.
- (f) Strobe lights should not be operating when flying through overcast and clouds, since reflected light can produce spacial disorientation. Do not operate strobe lights in close proximity to ground.
- (g) The rudder pedals are suspended from a torque tube which extends across the fuselage. The pilot should become familiar with the proper positioning of his feet on the rudder pedals so as to avoid interference with the torque tube when moving the rudder pedals or operating the toe brakes.
- (h) In an effort to avoid accidents, pilots should obtain and study the safety related information made available in FAA publications such as regulations, advisory circulars, Aviation News, AIM and safety aids.

- (i) The shape of the wing fuel tanks is such that in certain maneuvers the fuel may move away from the tank outlet. If the outlet is uncovered, the fuel flow will be interrupted and a temporary loss of power may result. Pilots can prevent inadvertent uncovering of the outlet by avoiding maneuvers which could result in uncovering the outlet.

Extreme running turning takeoffs should be avoided as fuel flow interruption may occur.

Prolonged slips or skids which result in excess of 2000 ft. of altitude loss, or other radical or extreme maneuvers which could cause uncovering of the fuel outlet must be avoided as fuel flow interruption may occur when tank being used is not full.